

**System User's Guide
for the
EOSDIS Test System (ETS)
MPS/Aura Simulator**

**Release 2.0
June 2001**

Prepared Under Contract NAS9-98100
by Computer Sciences Corporation

**System User's Guide
for the
EOSDIS Test System (ETS)
MPS/Aura Simulator**

Release 2.0

June 2001

Prepared Under Contract NAS9-98100
by Computer Sciences Corporation

Prepared by:

J. K. Carlson, CSC Date

Reviewed by:

E. Quintin Date
ETS Technical Lead, CSC

D. Green Date
ETS Software Manager, CSC

Quality assured by:

L. Hepfer Date
QA Officer, CSC

Approved by:

W. Fuller Date
ETS Manager, Code 581

About This Document

This document is the System User's Guide for the Scalable, Integrated, Multimission, Simulation Suite (SIMSS) Aura Simulator developed for the National Aeronautics and Space Administration (NASA) Goddard Space Flight Center (GSFC). This simulator is commonly referred to as the MPS/Aura simulator. The simulator is one of the deliverables of the EOSDIS Test System (ETS) Development Task under the CSOC contract. The System User's Guide provides an overview of operational concepts and procedures for this simulator. This document is approved by GSFC Code 581, and will be maintained by Computer Sciences Corporation (CSC) under the CSOC contract.

Who Should Use This Document

This document is for anyone who wishes to use the MPS/Aura Simulator. To use this simulator effectively you should already be familiar with the basics of the Windows NT Operating System as well as be familiar with the EOS Aura Spacecraft.

Document Overview

The MPS/Aura simulator is built with SIMSS components. It contains several generic modules, InputIP, OutputIP, LogModule, SerialInput, SerialOutput, Scenario, Txfile and VC Processor. It also has two modules, EOSGS and SCAura, that were customised for the EOS Aura mission. This document has also been assembled with SIMSS generic and Aura specific information.

The first chapter provides a complete description of the SIMSS client and server project user interface. It describes the core operations of building, configuring, saving, restoring and running a project. All users should read this chapter to become familiar with SIMSS terminology and the common project user interface that will be referenced in later chapters.

Next are chapters that describe each of the modules that have been delivered as components of MPS/Aura. For each module, there is information on how to link it to other SIMSS modules, how to configure it, and how to control its run-time operations.

Chapter	Module Name	Description
EOSGS	EOSGS	EOS Ground Station Module
SCAura	SCAura	Spacecraft Module for Aura
IP	InputIP, OutputIP	Input and Output Internet Protocol Modules
Log	LogModule	Log Module
SN	Scenario	Scenario Module
SI	SerialInput	Serial Input Module
SO	SerialOutput	Serial Output Module
TxFile	TxFile	Transmit File Module
VC Processor	VC Processor	Virtual Channel Processor Module

The final chapter provides a list of acronyms.

SIMSS CLIENT-SERVER ARCHITECTURE	1
SIMSS-1.0 OVERVIEW	1
SIMSS-2.0 INSTALLING A NEW RELEASE.....	2
SIMSS-2.1 INSTALLING THE CLIENT	2
SIMSS-2.2 INSTALLING THE SERVER	2
SIMSS-3.0 CONFIGURATION FILES	2
SIMSS-3.1 CLIENT/PROPERTIES/SERVERS.TXT	2
SIMSS-3.2 SERVER/PROPERTIES/PROPERTY.TXT.....	3
SIMSS-4.0 RUNNING A SIMSS APPLICATION.....	3
SIMSS-4.1 APPLICATION STARTUP SEQUENCE.....	4
SIMSS-5.0 SIMSS APPLICATION DISPLAYS	5
SIMSS-5.1 SIMSS CLIENT MAIN WINDOW.....	5
<i>SIMSS-5.1.1 File Menu.....</i>	5
<i>SIMSS-5.1.2 Edit Menu.....</i>	5
<i>SIMSS-5.1.3 Project Menu.....</i>	5
SIMSS-5.1.3.1 Add Project.....	5
SIMSS-5.1.3.2 Restore Project	5
<i>SIMSS-5.1.4 Help Menu.....</i>	6
SIMSS-5.2 PROJECT WINDOW	6
<i>SIMSS-5.2.1 Project System Menu.....</i>	7
SIMSS-5.2.1.1 Connect to Server.....	7
SIMSS-5.2.1.2 Disconnect from Server.....	7
SIMSS-5.2.1.3 Save Project.....	7
SIMSS-5.2.1.4 Event Message Filtering.....	8
SIMSS-5.2.1.5 Show Event Log	8
<i>SIMSS-5.2.2 Project Module Menu.....</i>	8
SIMSS-5.2.2.1 Add Module	8
SIMSS-5.2.2.2 Create Links	9
SIMSS-5.2.2.3 Design Mode	10
SIMSS-5.2.2.4 Module Pop-Up Menu.....	10
<i>SIMSS-5.2.3 Project Run Menu</i>	11
SIMSS-5.2.3.1 Locking a Project	11
SIMSS-5.2.3.2 Unlocking a Project.....	11
SIMSS-5.2.3.3 Running a Project.....	11
SIMSS-5.2.3.4 Stopping a Project	12
<i>SIMSS-5.2.4 Project Directive Region.....</i>	12
SIMSS-5.2.4.1 Directives/Scenario Files.....	12
SIMSS-5.2.4.2 Set Directive.....	12
SIMSS-5.2.4.2.1 Set directive using expressions.....	13
SIMSS-5.2.4.2.2 Set directive using arithmetic expressions.....	13
SIMSS-5.2.4.2.3 Set directive using arithmetic and Boolean functions	13
SIMSS-5.2.4.2.4 Set directive using mnemonics in expressions	14
SIMSS-5.2.4.2.5 Intermediate variables (A-Z)	14
SIMSS-5.2.4.3 Setbuffer Directive	14
SIMSS-5.2.4.4 Get Directive	15
SIMSS-5.2.4.5 Getbuffer Directive	15
<i>SIMSS-5.2.5 Project Event Log Region</i>	16
EOS GROUND STATION MODULE (EOSGS).....	17
EOSGS-1.0 OVERVIEW	17
EOSGS-2.0 INPUTS	17
EOSGS-3.0 OUTPUTS.....	17

System User's Guide for MPS/Aura Release 2.0

EOSGS-4.0 CONTAINER ITEMS	17
EOSGS-4.1 COUNTERS	17
EOSGS-4.2 BUFFERS	17
EOSGS-4.3 GROUND MESSAGE HEADER (GMH) FIELDS	18
EOSGS-4.4 EDOS DATA UNIT (EDU) HEADER FIELDS	18
EOSGS-5.0 DISPLAYS.....	19
EOSGS-5.1 CONFIGURATION.....	19
EOSGS-5.2 RUN-TIME	19
<i>EOSGS-5.2.1 Show Status.....</i>	19
<i>EOSGS-5.2.2 Show Command Packet.....</i>	20
<i>EOSGS-5.2.3 Show Telemetry Channel 1 Packet.....</i>	20
<i>EOSGS-5.2.4 Modify Telemetry Header.....</i>	21
<i>EOSGS-5.2.5 Modify CLCW Header.....</i>	22
<i>EOSGS-5.2.6 Set/Display GMT</i>	23
EOSGS-5.3 ABOUT	23
EOSGS-6.0 SPECIAL OPERATING INSTRUCTIONS.....	23
SPACECRAFT SIMULATION MODULE FOR AURA (SCAURA).....	24
SCAURA-1.0 OVERVIEW	24
SCAURA-2.0 INPUTS	24
SCAURA-3.0 OUTPUTS	24
SCAURA-4.0 CONTAINER ITEMS	24
SCAURA-4.1 TELEMETRY CONTAINER ITEMS	24
<i>SCAURA-4.1.1 Telemetry Status and Control Container Items.....</i>	25
<i>SCAURA-4.1.2 Telemetry Point Container Items</i>	25
<i>SCAURA-4.1.3 Telemetry Packet Container Items.....</i>	25
<i>SCAURA-4.1.4 Telemetry Dump Packet Container Items</i>	26
<i>SCAURA-4.1.5 Telemetry VCDU Container Items</i>	27
SCAURA-4.2 COMMAND CONTAINER ITEMS	28
<i>SCAURA-4.2.1 Mission Specific Container Items</i>	28
<i>SCAURA-4.2.2 Command Validation/Debug Flags</i>	28
<i>SCAURA-4.2.3 Command Link Control Word Fields.....</i>	29
<i>SCAURA-4.2.4 Command Container Buffers</i>	30
<i>SCAURA-4.2.5 Command Triggering Scenarios Container Items</i>	30
<i>SCAURA-4.2.6 Command Submnemonic Container Items</i>	30
<i>SCAURA-4.2.7 Command Counter Container Items</i>	31
SCAURA-4.3 DATABASE CONTAINER ITEMS	32
SCAURA-5.0 DISPLAYS	32
SCAURA-5.1 CONFIGURATION MENU	32
<i>SCAURA-5.1.1 Load Database</i>	33
<i>SCAURA-5.1.2 Select Simulation Mode.....</i>	33
SCAURA-5.2 RUN-TIME MENU.....	34
<i>SCAURA-5.2.1 Main Display.....</i>	34
SCAURA-5.2.1.1 Telemetry Menus	34
<i>SCAURA-5.2.1.1.1 Modify Packet Display</i>	35
<i>SCAURA-5.2.1.1.2 Telemetry Packet Display</i>	35
<i>SCAURA-5.2.1.1.3 Telemetry Status Display</i>	36
<i>SCAURA-5.2.1.1.4 Control Packet Display</i>	37
<i>SCAURA-5.2.1.1.5 Initiate Dump Packets</i>	37
<i>SCAURA-5.2.1.1.6 Display/Set Container Items</i>	38
<i>SCAURA-5.2.1.1.7 Display Container Buffer.....</i>	38
<i>SCAURA-5.2.1.1.8 Modify CCSDS Unsegmented Time Code</i>	39
<i>SCAURA-5.2.1.1.9 Display APID Status.....</i>	40
SCAURA-5.2.1.2 Command Menu	40
<i>SCAURA-5.2.1.2.1 Display Command Status</i>	41
<i>SCAURA-5.2.1.2.2 Modify Validation Criteria</i>	42

System User's Guide for MPS/Aura Release 2.0

SCAURA-5.2.1.2.2.1 None Validation Option.....	42
SCAURA-5.2.1.2.2.2 Validation of CLTU Start and Tail Sequences	42
SCAURA-5.2.1.2.2.3 BCH Error Code Validation Option	43
SCAURA-5.2.1.2.2.4 Transfer Frame Header Validation Option	43
SCAURA-5.2.1.2.2.5 Farm (Valid Frame Sequence) Validation Option	43
SCAURA-5.2.1.2.2.6 User Command Packet Header Validation Option	44
SCAURA-5.2.1.2.3 Display Spacecraft Packet	44
SCAURA-5.2.1.2.4 Display Instrument Packet.....	44
SCAURA-5.2.1.2.5 Override CLCWs.....	44
SCAURA-5.2.1.2.6 Display Spacecraft Load.....	45
SCAURA-5.2.1.3 Time.....	46
SCAURA-5.2.1.3.1 Modify Times Display	46
SCAURA-5.3 REMOVE	47
SCAURA-5.4 ABOUT	47
SCAURA-6.0 SPECIAL OPERATING INSTRUCTIONS	47
SCAURA-6.1 SERIAL MODE OPERATION	47
SCAURA-6.2 TRIGGERING SCENARIOS WITH COMMANDS	47
<i>SCAURA-6.2.1 Using the Default Scenario Directory</i>	47
<i>SCAURA-6.2.2 Using an Alternate Scenario Directory.....</i>	48
<i>SCAURA-6.2.3 Update/Replace Command Trigger Definitions.....</i>	48
INTERNET PROTOCOL (IP) MODULES	49
IP-1.0 OVERVIEW	49
IP-2.0 INPUTS	49
IP-3.0 OUTPUTS.....	49
IP-4.0 CONTAINER ITEMS	49
IP-5.0 DISPLAYS.....	49
IP-5.1 CONFIGURATION.....	50
<i>IP-5.1.1 Configure IP Type Field</i>	50
<i>IP-5.1.2 Configure Receiver (or Sender) Address Box</i>	50
<i>IP-5.1.3 Configure Source (or Destined) Address Box.....</i>	50
<i>IP-5.1.6 Configure Variable Length Input (or Output) Field</i>	51
<i>IP-5.1.7 Configure Frame Size Field.....</i>	52
IP-5.2 RUN-TIME	52
<i>IP-5.2.1 Show Status.....</i>	52
<i>IP-5.2.2 Show Raw Packet.....</i>	53
<i>IP-5.2.4 Resume.....</i>	55
<i>IP-5.2.5 Stop</i>	55
<i>IP-5.2.6 Restart.....</i>	55
IP-5.3 ABOUT	55
IP-6.0 SPECIAL OPERATING INSTRUCTIONS	55
LOG MODULE.....	56
LOG-1.0 OVERVIEW	56
LOG-2.0 INPUTS.....	56
LOG-3.0 OUTPUTS	56
LOG-4.0 CONTAINER ITEMS	56
LOG-5.0 DISPLAYS	56
LOG-5.1 CONFIGURATION	56
<i>Log-5.1.1 Log File Name</i>	57
<i>Log-5.1.2 Maximum Log Size (bytes).....</i>	57
<i>Log-5.1.3 Packet Size (bytes).....</i>	57
<i>Log-5.1.4 Log With Header</i>	57
<i>Log-5.1.5 Variable Length Output.....</i>	57
LOG-5.2 RUN-TIME.....	58
<i>Log-5.2.1 Show Status.....</i>	58

System User's Guide for MPS/Aura Release 2.0

<i>Log-5.2.2 Pause/Resume</i>	58
<i>Log-5.2.3 Stop/Restart</i>	58
LOG-5.3 ABOUT	59
LOG-6.0 SPECIAL OPERATING INSTRUCTIONS	59
SCENARIO (SN) MODULE.....	60
SN-1.0 OVERVIEW	60
SN-2.0 INPUTS.....	60
SN-2.1 SERVER/PROPERTIES/PROPERTY.TXT	60
SN-2.2 MODULE TRIGGERED SCENARIOS	60
SN-2.3 SCENARIO FILE INPUT	60
<i>SN-2.3.1 Scenario File Contents</i>	61
SN-2.3.1.1 Specifying Modules to Receive Scenario Directives	61
SN-2.3.1.2 Specifying Conditional Expressions	62
SN-2.3.1.3 Simple Scenario Example	62
SN-2.3.1.4 IF Scenario Example	62
SN-2.3.1.5 While Scenario Example	63
SN-3.0 OUTPUTS	63
SN-4.0 CONTAINER ITEMS	63
SN-5.0 DISPLAYS	64
SN-5.1 CONFIGURE	64
SN-5.2 RUN-TIME.....	64
<i>SN-5.2.1 Scenario Control Display</i>	64
<i>SN-5.2.2 Scenario File Browser</i>	65
SN-5.3 ABOUT	66
SN-6.0 SPECIAL OPERATING INSTRUCTIONS	66
SN-6.1 BUILT-IN DELAYS IN SCENARIO FILES	66
SN-6.2 STOPPING NESTED OR TRIGGERED SCENARIOS	67
SERIAL INPUT (SI) MODULE.....	68
SI-1.0 OVERVIEW	68
SI-2.0 INPUT	68
SI-3.0 OUTPUT	68
SI-4.0 CONTAINER ITEMS	68
SI-5.0 DISPLAYS.....	68
SI-5.1 CONFIGURATION	68
SI-5.2 RUN-TIME	70
<i>SI-5.2.1 Display Status</i>	71
<i>SI-5.2.2 Display Dump</i>	71
<i>SI-5.2.3 Resume</i>	72
<i>SI-5.2.4 Pause</i>	72
SI-5.3 REMOVE.....	72
SI-5.4 ABOUT	73
SI-6.0 SPECIAL OPERATING INSTRUCTIONS	73
SERIAL OUTPUT (SO) MODULE	74
SO-1.0 OVERVIEW	74
SO-2.0 INPUT	74
SO-3.0 OUTPUT	74
SO-4.0 CONTAINER ITEMS	74
SO-5.0 DISPLAYS	74
SO-5.1 CONFIGURATION	74
SO-5.2 RUN-TIME.....	76
<i>SO-5.2.1 Display Status</i>	76
<i>SO-5.2.2 Display Dump</i>	76
<i>SO-5.2.3 Resume</i>	77

System User's Guide for MPS/Aura Release 2.0

<i>SO-5.2.4 Pause</i>	77
SO-5.3 REMOVE.....	77
SO-5.4 ABOUT	77
SO-6.0 SPECIAL OPERATING INSTRUCTIONS	77
TRANSMIT FILE (TXFILE) MODULE	78
TXFILE-1.0 OVERVIEW.....	78
TXFILE-2.0 INPUTS.....	78
TXFILE-3.0 OUTPUTS	78
TXFILE-4.0 CONTAINER ITEMS.....	78
TXFILE-5.0 DISPLAYS	79
TXFILE-5.1 CONFIGURATION DISPLAYS	79
TXFILE-5.2 RUN-TIME DISPLAYS	79
<i>TxFile-5.2.1 Status Display.....</i>	80
<i>TxFile-5.2.2 Transmit Buffer Display.....</i>	80
<i>TxFile-5.2.3 Send From File.....</i>	81
TxFile-5.2.3.1 File Browsing	83
TxFile-5.2.3.2 File Types.....	83
TxFile-5.2.3.3 Example 1 Manual Mode Transmission	84
TxFile-5.2.3.4 Example 2 Auto-Complete File Transmission	85
TxFile-5.2.3.5 Example 3 Auto-Blocks Transmission (Raw Fixed Data Files Only).....	86
TxFile-5.2.3.6 Example 4 Use of Log File Timing (Log Files Only)	87
TxFile-5.2.3.7 Example 5 Serial Transmission Mode.....	88
TXFILE-5.3 ABOUT DISPLAY	89
TXFILE-6.0 SPECIAL OPERATING INSTRUCTIONS	89
GENERIC VC PROCESSOR MODULE	90
VC PROCESSOR-1.0 OVERVIEW	90
VC PROCESSOR-2.0 INPUTS	90
VC PROCESSOR-3.0 OUTPUTS	90
VC PROCESSOR-4.0 CONTAINER ITEMS	90
VC PROCESSOR-5.0 DISPLAYS	91
VC PROCESSOR -5.1 CONFIGURE	91
<i>VC Processor-5.1.1 Main Configuration Window.....</i>	91
<i>VC Processor-5.1.2 Set Channel.....</i>	92
<i>VC Processor-5.1.3 Display Offset.....</i>	92
VC PROCESSOR-5.2 RUN.....	93
<i>VC Processor-5.2.1 Show Status.....</i>	93
<i>VC Processor-5.2.2 Display VC</i>	94
<i>VC Processor-5.2.3 ReConfigure.....</i>	94
ACRONYMS.....	95

SIMSS Client-Server Architecture

The Scalable, Integrated, Multimission Simulation Suite (SIMSS) is a distributed, component-based, plug-and-play, client-server system useful for performing real-time simulations and communications testing in support of NASA projects.

SIMSS-1.0 Overview

SIMSS runs on one or more Windows NT workstations. It is designed to be user-configurable or to use predefined configurations for routine operations.

Terminology:

- Client: The workstation on which the user interface runs. It also refers to the applications making up the user interface.
- Server: The workstation on which the actual data processing is performed. It also refers to the applications making up the data processing component.
- Module: A self-contained SIMSS component that receives, processes, or transmits data, or any combination of the three.
- Channel: An interface or port through which a module receives or transmits data. A module may have zero to many channels.
- Link: A directional connection between module channels. A link connects an output channel of one module with the input channel of another module.
- Project: A collection of modules and links intended to perform a specific function such as spacecraft simulation, data quality monitoring, or data conversion.
- Event Message: A time-tagged text message generated by any module to inform the operator. Event messages may report warning or error conditions as well as successful activities.
- Directive: A text-based command line entry that operators submit to individual modules. The directive entry line window is below the configuration window in the main SIMSS display.
- Container: A repository internal to each module that contains all of the vital data for that module. The container is used to exchange data between the client and server. Built-in functions of the container support save and restore operations.
- Scenario: A file that contains directives. A scenario module may execute this file in order to send a timed repeatable sequence of directives to a linked module.

SIMSS-2.0 Installing A New Release

SIMSS-2.1 Installing the Client

To install the SIMSS client, run jdk1_2_1-win.exe located in the \jdk folder on the delivery CD. After JDK1.2.2 is installed, the next step is to run setup.exe in the \client folder on the CD and follow the prompts. Upon completion of the client installation, a SIMSS Client icon will be installed on the desktop. The SIMSS Client icon will point to the executable directory for the client software. Below this directory are three additional directories: images, properties, and save.

Directory	Description
images	Contains bitmapped image files.
properties	Contains client configuration files.
save	This directory is where client information is stored when projects are saved. The user may want to delete old files from this directory. (Files with the same names should also be deleted from the Server save directory)

SIMSS-2.2 Installing the Server

To install the SIMSS server, run *setup.exe* in the \server folder on the CD and follow the prompts. Upon completion of the server installation, a SIMSS Server icon will be installed on the desktop. The SIMSS Server icon will point to the executable directory for the server software. Below this directory are four additional directories: elog, properties, save and scenario.

Directory	Description
elog	Contains event message log files. The user may want to delete old event message log files from this directory to reclaim disk space.
properties	Contains the server property.txt configuration file.
save	This directory is where server information is stored when projects are saved. The user may want to delete old files from this directory. (Files with the same names should also be deleted from the Client save directory)
scenario	Contains delivered scenario files. The user may store additional scenario files here.

Note: The user needs administrative rights in order to install the SIMSS Server.

SIMSS-3.0 Configuration Files

SIMSS-3.1 Client/Properties/Servers.txt

Before running the SIMSS Client, please check that the correct IP address for running the SIMSS Server is in the *properties/servers.txt* file. The format for entries in this file is:

Servername, IP address

Example:

localhost,127.0.0.1

SIMSS-3.2 Server/Properties/Property.txt

There are several parameters that may be configured in the server. Most of them are for debugging purposes. These parameters are stored in the *properties/property.txt* file. This file is read in each time that the server is started. The values used from the *property.txt* file are written into the server text window. The *property.txt* file contains descriptions of the parameters and their normal settings. Use caution in making modifications to this file. Some parameters that may be of interest to users are listed below.

Property	Description
EventMsgLogSize	This is a maximum event message log size. When this many event messages have been logged, the oldest messages will be overwritten. When set to zero, there is no limit on the number of event messages that are saved to the log.
DelOldLog	This flag is for deleting the old event log file on startup. (0=no, 1=yes). This is only effective if the event log file name is the same for each execution. Use with DefaultEventLogSave.
DefaultEventLogSave	This flag specifies use of the same event log file name for each execution (0=use different names, 1=use same name).
ConcurrentScenario	This flag applies to scenario modules in the project. The scenario mode may be set to 0 for serial operation or 1 for concurrent operation. It is normally set to 1. This parameter applies only to scenario files that are not under direct operator GUI control, such as scenario files started by other scenario files. If too many scenarios run concurrently, there could be system resource issues.

SIMSS-4.0 Running a SIMSS Application

The SIMSS modular architecture can support a variety of applications by connecting generic and mission-specific modules in different combinations. The general steps for starting up any SIMSS project are summarized in the next section. Detailed examples of each of these steps are provided in SIMSS-5.0, which describes the graphical user interface (GUI).

Every SIMSS application must run within a project. Each project consists of interconnected executable software modules. Every software module may have configuration and run-time displays. Every module that accepts operator directives can execute the directives described later in this chapter. Every module that executes directives may also be configured to accept directives from a scenario file. Every module that generates event messages for the operator sends them to the event log region of its project window.

Other chapters in this system user's guide are devoted to the various generic and mission-specific SIMSS modules. Please refer to these chapters for detailed information on module-specific configuration and run-time operations.

SIMSS-4.1 Application Startup Sequence


Startup Steps	Description
1) Start the Server	Double-click the Server icon on the PC desktop. When the Server is started, a text window is created.
2) Start the Client	Double-click the SIMSS Client icon on the desktop. When the Client is started, a Client text window is created and then the graphical user interface is started with the SIMSS Client main window.
3) Add (or Restore) a Project	Click on the SIMSS Client main window's Project menu and select "Add Project". Or, the "Restore From" selection can be used to load a previously saved project. A project window is created within the main window. If a previously saved project is restored, skip to step 7.
4) Connect Project to Server	In the project window, click the System menu and select the "Connect" option. A list of available servers will be shown. Select a server for the connection. When you connect to the server, the message in the lower, left-hand corner of the project changes from "Status" to "Project Loaded."
5) Add Modules	In the project window, click the Module menu and select "Add Module". From the Module Selection window, click on the module to be added and the OK button. Click again in the project window for placement of the module's icon. Repeat this step until all desired modules have been added.
6) Create Links Note: Refer to the module specific chapters for input and output channel data descriptions in order to link the output channels to the appropriate input channels!	In the project window, click the Module menu and select "Create Links". Click on a module's border and drag the cursor to the border of another module and click again. If either module has multiple links, a popup window will appear for specification of the exact links. Repeat this step to create all desired links. To cancel link creation mode, click on the Module menu and select "Design".
7) Configure Modules	Click in the center of the module and select "Configure" from the popup menu. Perform module-specific configurations. Repeat for as many modules as needed.
8) Lock the Project	In the project window, click the Run menu and "Lock".
9) Save the Project (optional)	Click the project window's System menu and select "Save Project". Specify a name for the project save file.
10) Run the Project	In the project window, click the Run menu and select "Run". All of the modules in the project will be started. Click in the center of any module to access its run-time options and displays.

SIMSS-5.0 SIMSS Application Displays

This section describes the graphical user interface common to all SIMSS applications. Every application has graphical client and project windows. Every module that accepts operator directives can execute the directives described later in this SIMSS chapter. Every module that generates event messages sends them to the event log region of its project window.

SIMSS-5.1 SIMSS Client Main Window

When the SIMSS Client is started, the main window appears.



SIMSS-5.1.1 File Menu

The File menu contains an "Exit" option.

SIMSS-5.1.2 Edit Menu

The Edit menu contains a "Look and Feel" option. When this option is chosen, the operator may select from "System", "Metal", "Motif", or "Windows". The default setting is "Metal".

SIMSS-5.1.3 Project Menu


The Project menu contains two selections, "Add Project" and "Restore Project".

SIMSS-5.1.3.1 Add Project

To create a new project, select the "Add Project" item from the Project menu. This will add a project window within the SIMSS Client window. In future releases, multiple project windows may be created within the main window.

SIMSS-5.1.3.2 Restore Project

To restore an existing project, select the "Restore From" item from the Project menu. The following file selection screen will appear.




The system will search the save directory by default but another directory may be selected by clicking the Save Folder button. Select a file and click the **Open** button. Click on the **Cancel** button to dismiss the display without restoring a project.

SIMSS-5.1.4 Help Menu

The Help menu contains an "About" option that provides client version information.

SIMSS-5.2 Project Window

When a project is added (or restored) its project window is displayed.



The project window contains a System menu, a Module menu and a Run menu. At the bottom left of the project window is a status field. At the bottom right is the directive region of the screen. Below the status and directive lines is the optionally displayed event log region. The log region is not shown in this example.

SIMSS-5.2.1 Project System Menu

The System menu on the Project window contains the following choices.

System Menu Item	Description
Connect	Connects the project to a server
Disconnect	Disconnects the project from a server
Save Project	Saves the project design to file
Filter Events...	Change event message filtering
Show Event Log	When this option is enabled, the event log portion of the Project window is displayed.

SIMSS-5.2.1.1 Connect to Server


The client must be connected to a server in order to function. To make a connection to a server, select the “Connect” option from the System menu. A menu of available servers will be displayed. Click to select a server for the connection. In the above picture, only one server was available. After the client has been connected to a server, the “Disconnect” option will be enabled on the System menu and the “Connect” option will be disabled.

SIMSS-5.2.1.2 Disconnect from Server

To disconnect the client from the server, select the “Disconnect” option from the System menu. After the client has disconnected from the server, the “Disconnect” option will be disabled on the System menu and the “Connect” option will be enabled.


SIMSS-5.2.1.3 Save Project

This option allows the user to store the project’s design to a file. Different design configurations of SIMSS modules may be desired for different testing environments. To save the project, select the “Save Project” option. The following screen will appear.



Enter the file name for storage of the current project and click the **OK** button to have project information written into it. The file name will have “.ser” appended to the end. Clicking **Cancel** will close this window without performing a save.

SIMSS-5.2.1.4 Event Message Filtering



When "Filter Events..." is selected, the Event Message Filtering screen appears. This image shows the default filtering scheme. Only event messages with the selected colors will be displayed in the event message region of the screen.

All event messages will continue to be generated and written into the event message log file.

To disable the display of any of these event message types, clear its checkbox.

To enable the display of any of these event message types, check its checkbox.

Use the **Apply** button for changes to take effect.
Use the **Close** button to dismiss this screen.

SIMSS-5.2.1.5 Show Event Log

Each project has an event log that displays time-tagged event messages received from all of its modules. The event log may be optionally displayed as a scrolling region at the bottom of the project window. Modules may send various color-coded event messages to the event log during configuration and run-time operations.


SIMSS-5.2.2 Project Module Menu

The Module menu on the Project window contains the following choices.

Module Menu Item	Description
Add Module	Add a module to the project's design diagram
Create Links	Create a link between modules
Design	Allows editing of the project design diagram

SIMSS-5.2.2.1 Add Module

To add a module to the project, select the "Add Module" option from the Module menu.



A list of the modules available from the server will be displayed. Click to select a module and then click the **OK** button.

Position the cursor within the project window where the top left corner of the module's symbol should be drawn and click. A rectangle representing the module will be drawn at that location. The rectangle will have a wide cyan border while in Design mode.


If a module is added that accepts operator directives, the directive region of the project window becomes accessible.

SIMSS-5.2.2.2 Create Links

Links are used to connect the input and output channels between modules for a given project. In the example shown below, the output channel of an Input IP module is linked to an input channel of a Ground Station module. An output channel from the Ground Station module is linked to an input channel of the Output IP module.

To create a link,

- select the “Create Links” option from the Module menu,
- position the crosshair cursor on the highlighted edge of the source module and click,
- move the cursor to the destination module’s edge and click again.





When multiple links are defined for a module, the user will be prompted to choose a channel number for the source and destination links as appropriate. Refer to module-specific information for the number of input and output channels a module can have and how they should be configured.

The cursor remains in Create Links mode to allow for the creation of additional links. The cursor appears as a crosshair symbol until a different module menu option is selected.

If multiple links are created between two modules, additional clicks may be done to anchor the link lines apart for visibility. The operator may click on a link line to review the channel numbers of the modules it connects. A popup window provides the source and destination channel numbers.


SIMSS-5.2.2.3 Design Mode

After the “Create Links” option has been used, the cursor remains as a crosshair symbol and the system remains in link creation mode. To cancel this mode, click the “Design” option from the Module menu. The cursor is changed back into a pointer symbol and may be used to select items of the design diagram for modification.

SIMSS-5.2.2.4 Module Pop-Up Menu

Clicking in the center of a module activates a pop-up menu with the following choices.

Module Pop-Up Menu	Description
Configure	Provides access to module-specific configuration options.
Run-time	Provides access to module-specific run-time options.
Remove	Removes the module from the project.
About	Provides information about the module.




The actions initiated by the “Configure” and “Run-time” options are different for every module and are described in the other chapters of this system user’s guide that are dedicated to specific modules.

SIMSS-5.2.3 Project Run Menu

The Run menu on the Project window contains the following choices.

Run Menu Item	Description
Lock/Unlock	Locks/Unlocks the project’s design diagram
Run/Stop	Starts/Stops the project’s execution

SIMSS-5.2.3.1 Locking a Project



Prior to running a project, the user must lock its design by clicking the “Lock” option from the Run menu. After the design is locked, the “Lock” option is replaced by the “Unlock” option and the “Run” option becomes available on the Run menu.

SIMSS-5.2.3.2 Unlocking a Project

Click the “Unlock” option from the Run menu to allow modification to the project’s design diagram. The “Unlock” option is then replaced on the Run menu with a “Lock” option.

SIMSS-5.2.3.3 Running a Project

Click the “Run” option from the Run menu to start running all of the modules of the project. The borders of the modules will change to green to indicate run mode. The “Run” option is then replaced with a “Stop” option.

Click on specific modules to get their pop-up menus. See SIMSS-5.2.2.4 Module Pop-Up Menu for an example. Click on the Run-time option for module-specific displays or actions. Please refer to the module-specific chapters in this system user's guide for information on each module's configuration and run-time displays.

SIMSS-5.2.3.4 Stopping a Project

Click the “Stop” option from the Run menu to stop execution of the modules of the project. The borders of the modules will change to red to indicate the stopped condition. The “Stop” option is then replaced with a “Run” option on the Run menu.

SIMSS-5.2.4 Project Directive Region

If any module in a project accepts operator directives, the directive region in the lower right side of the project window frame is activated. If the project's event log is being shown, it appears below this region. The directive region has a module indicator button and a data entry field. When the module indicator button is clicked, a list of the modules accepting directives is shown. Click to select the module to process a directive. The button is labeled with the currently selected module. In the example below, the Input IP module is selected. Click in the data entry field to the right of the module button to start entering a directive. Alternatively, click on the down arrow to the right of the field to view up to ten previously entered directives. A previous entry may be selected, optionally edited, and submitted. Use the keyboard's enter key to send the directive to the module. Directives are available to any module that accepts directives and has container variables.



SIMSS-5.2.4.1 Directives/Scenario Files

This section describes all of the directives currently defined for all SIMSS modules that accept operator directives. These directives may be placed in text files to be used as scenario files. Any module that processes directives can also receive directive lines read from a scenario file by the Scenario module. In addition to the directives described in this section, there are directives that are executed only by the Scenario module. These scenario directives control the timing and conditional execution of scenario directive lines. Please see the chapter on the Scenario module for more information on creating and executing scenario files. Refer to the container descriptions in each module's chapter for the names (mnemonics) of container items for each module.

SIMSS-5.2.4.2 Set Directive

The **set** directive may be used to change the value of any modifiable variable in the container for the indicated module. The format of the **set** directive is

set name value

where *name* is a container variable name and *value* is either a decimal, octal, or hexadecimal number. Octal numbers are identified by a leading zero. Hex numbers are identified by a leading 0x. The names of variables are provided in the container

description for each module. If the variable is successfully set, an event message of the form

“module: *name* set to *value*”

informs the operator of the change. If the variable name is not recognized or the variable cannot be modified, an event message of the type

“module: *name* invalid, read-only or not found“

will inform the operator. If unsuccessful, verify that the module indicator is correct, that the variable name spelling is correct and that the variable is not defined as read-only.

SIMSS-5.2.4.2.1 Set directive using expressions

More complicated assignments of values to container items are possible. Telemetry mnemonics (or any other type of container item) may be set to values derived from any combination of arithmetic expressions, arithmetic functions, Boolean functions, and other container items. These directives may be used to create sophisticated scenario files. The length of an individual set directive is limited to 100 characters. Intermediate variables which have single character names have been created in part to allow writing of expressions that would otherwise be too long. In order to use any of the following expressions, specification of an equal sign in one of the following forms is required (=, +=, -=, *=, /=, ^=) after the mnemonic name and before the expression. The following sections provide syntax information and examples of set directives using expressions.

SIMSS-5.2.4.2.2 Set directive using arithmetic expressions

A container item may be set to an arithmetic expression using the symbols for addition (+), subtraction (-), division (/), multiplication (*) and raise to a power (^). Parentheses are recommended to specify the precedence order.

set mnemonic = 2 * (7^3)

SIMSS-5.2.4.2.3 Set directive using arithmetic and Boolean functions

A container item may also be set to an arithmetic expression using functions from the following table. The following rules apply:

- The function names must be in lower case.
- The parentheses around the function argument are required syntax.
- Arguments to the Boolean functions must be in decimal.
- The Boolean functions perform a bit-wise AND, OR, etc.

Function Description	Set directive example
Arcsine (x)	Set mnemonic = asin (x)
Arccosine (x)	Set mnemonic = acos (x)
Arctangent (x)	Set mnemonic = atan (x)
Degrees to radians (x)	Set mnemonic = dtor (x)
Radians to degrees (x)	Set mnemonic = rtod (x)
Square root (x)	Set mnemonic = sqrt (x)
Log (x)	Set mnemonic = ln (x)

Exponent (x)	Set mnemonic = exp (x)
Tangent (x)	Set mnemonic = tan (x)
Sine (x)	Set mnemonic = sin (x)
Cosine (x)	Set mnemonic = cos (x)
Sine in radians (x)	Set mnemonic = rsin (x)
Cosine in radians (x)	Set mnemonic = rcos (x)
Arcsine in radians (x)	Set mnemonic = rasin (x)
Arccosine in radians (x)	Set mnemonic = racos (x)
Arctangent in radians (x)	Set mnemonic = ratan (x)
Add x to mnemonic's current value.	Set mnemonic += x
Subtract x from mnemonic's current value	Set mnemonic -= x
Multiply mnemonic's current value by x	Set mnemonic *= x
Divide mnemonic's current value by x	Set mnemonic /= x
Raise mnemonic's value to the power of x	Set mnemonic ^= x
AND two values together	Set mnemonic = mnemonic and 1
OR two values	Set mnemonic = mnemonic or 7
OR two values and Negate the result	Set mnemonic = mnemonic nor 1
Exclusive OR two values	Set mnemonic = mnemonic xor 7
NAND two values	Set mnemonic = mnemonic nand 15

SIMSS-5.2.4.2.4 Set directive using mnemonics in expressions

Container names may be used instead of numbers in an expression. In the simplest case, a container item may be set to the current value of another container item.

```
set mnemonicA = mnemonicB
```

Container items may also be combined together to create expressions.

```
set mnemonicA = (mnemonicB + mnemonicC)/2
```

SIMSS-5.2.4.2.5 Intermediate variables (A-Z)

Twenty six intermediate variables have been created to allow for saving and using intermediate values. These variables are case-sensitive 'A' through 'Z', and must be entered in upper case. When set, these variables retain their values as long as the simulator runs. However, while they can be used in expressions, they are not container items and therefore, cannot be accessed directly via the get directive.

```
set A = mnemonicA
.
; other directives
.
; mnemonicA may have changed value, so
set mnemonicB = A
```

SIMSS-5.2.4.3 Setbuffer Directive

The **setbuffer** directive may be used to change the value of any modifiable buffer in the container for the indicated module. The format of the **setbuffer** directive is

[setbuffer | setbufferle | setbufferandlength] *buffername* <*offset*> [byte | word | dword] <*value*> <*value*> <*value*> ...

buffer. If "setbufferandlength" is used, then the size of the buffer is set to the total size of the data values set. The **setbuffer** directive entry line is limited to 100 characters. The names of alterable buffers are provided in the container description for each module. An example of setbuffer usage is:

```
setbuffer TlmPacket0140 20 byte 10 012 0xA
```

In this example, three bytes of the buffer TlmPacket0140 beginning at offset 20 are set to 10. If the buffer is successfully set, an event message of the form

“module: values set in buffer *buffername*”

informs the operator of the change. If the buffer name is not recognized or the buffer cannot be modified, an event message of the form

“module: *buffername* not found”

will inform the operator. If unsuccessful, verify that the module indicator is correct, that the buffer name spelling is correct, and that the buffer is not defined as read-only.

SIMSS-5.2.4.4 Get Directive

The **get** directive may be used to display the value of any variable in the container for the indicated module. The format of the **get** directive is

get *name*

If the name matches a variable in the module’s container, an event message of the form

“module: *name* = *value*”

is written to the event message log. If the name doesn’t match a container variable, an error event message of the form

“module: *name* not found”

will be produced. If unsuccessful, check the setting of the module indicator and the spelling of the container variable name.

SIMSS-5.2.4.5 Getbuffer Directive

The **getbuffer** directive may be used to change the value of any modifiable buffer in the container for the indicated module. The format of the **getbuffer** directive is

getbuffer[le] *buffername* <*offset*> [byte | word | dword] <*count*>

where *buffername* is a container buffer name, *offset* is the decimal byte offset to the first item to be set, the keywords “byte”, “word”, and “dword” indicate the size of data to retrieve at one time, and *count* is the number of items of data to retrieve. If the suffix “le” is added to the typein, the data is retrieved in little-endian (Intel) byte order before being displayed. The **getbuffer** directive entry line is limited to 100 characters. The names of alterable buffers are provided in the container description for each module. An example of **getbuffer** usage is:

```
getbuffer TlmPacket0140 20 byte 10
```

In this example, ten bytes of the buffer TlmPacket0140 beginning at offset 20 are retrieved. If there are no errors, an event message of the form

“module: *buffername* = 14 15 16 17 18 19 1a 1b 1c 1d”


informs the operator of the data with values in hexadecimal. If the buffer name is not recognized, an event message of the form

“module: *buffername* not found”

will inform the operator. If unsuccessful, verify that the module indicator is correct, and that the buffer name spelling is correct.

SIMSS-5.2.5 Project Event Log Region

Many SIMSS modules send informative, warning or error event messages to the project's event log during configuration and run-time operations. To open the event log region at the bottom of the project window, select the “Show Event Log” option from the System menu. The example shown includes event messages from **get** and **set** directives. The contents of this region may be filtered by event message type. See the section on Event Message Filtering under the project system menu for more information.



The screenshot shows a scrollable window containing event log entries. The entries are as follows:

```
10:00:50, August 27, 1999 inputIP DLL: input IP running
10:01:36, August 27, 1999 GSPM1: GcCmdCount invalid or not found.
10:01:57, August 27, 1999 GSPM1: GcCmdReceiveCount = 200
10:02:18, August 27, 1999 GSPM1: gscmdreceivecount set to 0
10:02:56, August 27, 1999 GSPM1: gscmdcount invalid, read-only, or not found.
```

EOS Ground Station Module (EOSGS)

EOSGS-1.0 Overview

The Earth Observing System (EOS) Ground Station (EOSGS) module is responsible for receiving telemetry, adding an EDOS Service header (ESH) to telemetry packets and transmitting the data as EDOS Data Units (EDUs). The EOSGS module provides a user interface to set EDOS Service header fields. The EOSGS module also receives Command Data Blocks (CDB), validates and strips off the Ground Message Header (GMH), and transmits Command Link Transmission Units (CLTUs).

EOSGS-2.0 Inputs

Ch.	Data expected	Validation performed	Processing performed
1	EDOS Command Data Blocks	Checks GMH fields	Ground Message Header removed, resulting data transmitted through output channel 1
2	Telemetry packets	None	EDOS Service Header added, resulting data transmitted through output channel 2
3	Command Link Control Words (CLCWs)	None	EDOS Service Header added, resulting data transmitted through output channel 3

EOSGS-3.0 Outputs

Ch.	Description
1	Command stream with acquisition sequence and CLTUs
2	EDOS Data Units (EDUs) containing telemetry packets
3	EDOS Data Units (EDUs) containing CLCWs

EOSGS-4.0 Container Items

The EOSGS module accepts operator directives and is capable of receiving directives from a Scenario module. Use the Set and Get directives to access items with a fixed type. Use the SetBuffer and GetBuffer directives on buffer types. Although names in the following tables contain upper and lower case, directive lines are not case-sensitive.

EOSGS-4.1 Counters

Name	Type	Description
GSCmdReceiveCount	Fixed	Number of command blocks received
GSTlmCh1TransmitCount	Fixed	Number of channel 1 blocks sent
GSClcwTransmitCount	Fixed	Number of channel 2 blocks sent

EOSGS-4.2 Buffers

Name	Type	Description
GSCmdBuffer	Buffer	Most recent command block received
GSTlmCh1Buffer	Buffer	Most recent telemetry block sent

GSClcwBuffer	Buffer	Most recent CLCW block sent
--------------	--------	-----------------------------

EOSGS-4.3 Ground Message Header (GMH) fields

Name	Type	Description
GSCmdEnableHeaderValidation	Fixed	GMH validation flag (1 = enabled, 0 = disabled)
GSCmdExpectedDestination	Fixed	GMH expected destination (1)
GSCmdExpectedMsgType	Fixed	GMH expected message type (3)
GSCmdExpectedSCID	Fixed	GMH expected SCID (0x00)
GSCmdExpectedSource	Fixed	GMH expected source (4)
GSCmdSequenceCount	Fixed	GMH expected sequence count (0)

EOSGS-4.4 EDOS Data Unit (EDU) Header fields

There are two sets of EDU container items, one set for each telemetry channel. Each EDU has an EDOS Service Header (ESH). To access fields from telemetry channel 1, insert "GsTlmch1" for "<ch>" in the names provided in the following table. To access fields from telemetry channel 2, insert "GsClcw" for "<ch>". For example, the container name for the ESH version field of the most recent channel 1 block is "EduHeaderGsTlmCh1Version". The container name for the same field in the most recent channel 2 block is "EduHeaderGsClcwVersion".

Name	Type	Description
EduHeader<ch>Version	Fixed	ESH version field
EduHeader<ch>SDUtype	Fixed	ESH SDU type field
EduHeader<ch>PortId	Fixed	ESH Port Id
EduHeader<ch>SourceDiscontinuityFlag	Fixed	ESH Source VCDU Discontinuity Flag
EduHeader<ch>PlaybackDataFlag	Fixed	ESH Contains Playback Data Flag
EduHeader<ch>RecoveryProcessingFlag	Fixed	ESH Recovery Processing Indicator
EduHeader<ch>TestDataFlag	Fixed	ESH Test Data Indicator
EduHeader<ch>CRCfailureFlag	Fixed	ESH CRC Failure Indicator
EduHeader<ch>PathDiscontinuityFlag	Fixed	ESH Path SDU Discontinuity Flag
EduHeader<ch>PktLengthErrorFlag	Fixed	ESH Packet Length Indicator
EduHeader<ch>PacketFillFlag	Fixed	ESH Packet Fill Indicator
EduHeader<ch>FirstSpare	Fixed	ESH First Spare Field
EduHeader<ch>SCID	Fixed	ESH SCID
EduHeader<ch>VCID	Fixed	ESH VCID
EduHeader<ch>FillLocation	Fixed	ESH Fill Data Location
EduHeader<ch>SecondSpare	Fixed	ESH Second Unused Field
EduHeader<ch>RSstatus	Fixed	ESH RS Validation Status
EduHeader<ch>HeaderErrorCount	Fixed	ESH VCDU Header Error Count
EduHeader<ch>TotalErrorCount	Fixed	ESH Total Error Count

EOSGS-5.0 Displays

To access the displays for this module, first click on the center of the module in the project window. The module pop-up menu will appear.

Module Pop-Up Menu Item	Description
Configuration	Setup expected Spacecraft ID (SCID)
Run-time	Access the Run-time menu for the module
Remove	Remove module from the project
About	Display generic module information

EOSGS-5.1 Configuration

There is one display available at configuration time.



This display is used to specify the expected Spacecraft Identifier (SCID) field for Ground Message Header validation. This value can be saved and restored as part of a project. Click **Apply** for the entered hexadecimal value to take effect. Use **Close** to dismiss the display.


This value will also be used in the SCID fields of outgoing EDOS Service Headers for housekeeping and CLCW telemetry unless overridden. See sections EOSGS-5.2.4 Modify Tlm Header and EOSGS-5.2.5 Modify CLCW Header for more information.

EOSGS-5.2 Run-time

There are six displays available from the Run-time menu.

Run-time Menu Item	Description
Show Status	Show counts of commands and telemetry packets
Show Cmd Packet	Display the command buffer
Show Tlm CH1 Packet	Display the housekeeping telemetry buffer
Modify Tlm Header	Modify header fields in housekeeping telemetry
Modify CLCW Header	Modify command link control word headers
Set/Display GMT	Display time fields for possible modification

EOSGS-5.2.1 Show Status




The status display shows the number of command blocks received and the number of housekeeping telemetry blocks transmitted. The **Reset** button may be used to zero out the counter in the same row.

EOSGS-5.2.2 Show Command Packet




The command packet display shows the header and, optionally (by pressing the **Dump** button), the contents of the most recent command block received, including the Ground Message Header.




The address field of the dump display may be toggled between hexadecimal and decimal display formats. The data portion may be toggled between hexadecimal and octal formats.


EOSGS-5.2.3 Show Telemetry Channel 1 Packet



The telemetry channel 1 packet display shows the header and, optionally (by pressing the **Dump** button), the contents of the most recent telemetry block as transmitted through telemetry channel 1 (module output channel 2).



EOSGS-5.2.4 Modify Telemetry Header




The Modify Tlm ESH display allows the operator to change values in the EDOS service header of housekeeping telemetry. Some of these changes are in effect for a single packet. Fields marked with an asterisk (*) in the following table are non-sticky. That is, they reset to zero after the transmission of one packet. To change the PB5 Time field, use the Set/Display GMT display.

Modify Tlm ESH Fields	Description
Version	ESH Version Number
SDU Type	SDU Type
EDOS Port ID	EDOS Port ID

Src Discontinuity*	Source VCDU Sequence Counter Discontinuity
Playback Data	VCDU Contains Playback Data
Recovery Proc	Recovery Processing Indicator
Test Data	Test Data Indicator
CRC Failure*	CRC Failure Indicator
Path Discontinuity*	Path SDU Source Seq. Counter Discontinuity
Pkt Length Err*	Packet Length Error
Packet Fill*	Packet Fill Indicator
First Spare	Spare field
Spacecraft ID	Spacecraft identification code
VCID	VCDU Id
Fill Location	Location 1 st byte Fill Data For Path SDU
Second Spare	Spare field
Reed-Solomon Status*	RS Error Control Flag
Header Error Count	Source VCDU Header Error Decode Results
Total Error Count	Source VCDU Error Decode Results

EOSGS-5.2.5 Modify CLCW Header




The ModifyCLCW ESH display allows the operator to change values in the EDOS service header of command link control words. Some of these changes are in effect for a single packet. Fields marked with an asterisk (*) in the following table are non-sticky. That is, they reset to zero after the transmission of one packet. To change the PB5 Time field, use the Set/Display GMT display.

Modify CLCW ESH Fields	Description
Version	ESH Version Number
SDU Type	SDU Type
EDOS Port ID	EDOS Port ID

Src Discontinuity*	Source VCDU Sequence Counter Discontinuity
Playback Data	VCDU Contains Playback Data
Recovery Proc	Recovery Processing Indicator
Test Data	Test Data Indicator
CRC Failure*	CRC Failure Indicator
Path Discontinuity*	Path SDU Source Seq. Counter Discontinuity
Pkt Length Err*	Packet Length Error
Packet Fill*	Packet Fill Indicator
First Spare	Spare field
Spacecraft ID	Spacecraft identification code
VCID	VCDU Id
Fill Location	Location 1 st byte Fill Data For Path SDU
Second Spare	Spare field
Reed-Solomon Status*	RS Error Control Flag
Header Error Count	Source VCDU Header Error Decode Results
Total Error Count	Source VCDU Error Decode Results

EOSGS-5.2.6 Set/Display GMT



This display shows the GMT time that is used in the EDOS Server Header. The user may **Set** the GMT time fields manually, **Keep** the time currently being used, or **Reset** time to the current system time.

Click the **Apply** button for the actions to take effect. Click the **Close** button to dismiss the window with no further action taken.

EOSGS-5.3 About

To display generic information about the EOSGS module, choose the “About” option from the module pop-up menu.

EOSGS-6.0 Special Operating Instructions

There are no special operating instructions for the current release.

Spacecraft Simulation Module for Aura (SCAURA)

SCAURA-1.0 Overview

The functions of the Spacecraft module for Aura (SCAURA) include generation and transmission of formatted telemetry packets, receipt of command link transmission units (CLTUs), and maintenance of GMT and spacecraft time. Spacecraft time is maintained as an offset from the Aura epoch and is inserted into telemetry packets prior to sending them to the Ground Station module. This module is also capable of displaying telemetry packets and received commands under operator direction.

SCAURA-2.0 Inputs

Ch.	Data expected	Validation performed	Processing performed
1	Scenario directives	Same as for operator directives	Directives from a scenario module are processed as if they had come from the user interface directive line.
2	Command stream	CCSDS and Aura specific	Commands parsed and validated per CCSDS standard and Aura extensions. Event messages generated on valid or invalid commands.

SCAURA-3.0 Outputs

The SCAURA module has 2 types of output channels. When the module is using IP mode, only channels 1 and 2 are used. When the module is using Serial mode only channel 3 is used.

Ch.	Description
1	IP mode Housekeeping telemetry packets
2	IP mode Command Link Control Words (CLCWs)
3	Serial mode telemetry transmission

SCAURA-4.0 Container Items

This module accepts operator directives and is capable of receiving directives from a Scenario module. Use the **Set** and **Get** directives to access items with a fixed or string type. Use the **SetBuffer** and **GetBuffer** directives on buffer types. Although names in the following tables contain upper and lower case, directive lines are not case sensitive.

SCAURA-4.1 Telemetry Container Items

The container items for telemetry processing fall into four major groups: control and status of telemetry streams, telemetry points, packet buffers, and VCDU buffers.

SCAURA-4.1.1 Telemetry Status and Control Container Items

Name	Type	Description
CLCWFrameCount	Fixed	CLCW channel transmitted count
CLCWPkt	Fixed	CLCW packet buffer
TlmChannel1Enabled	Fixed	Channel 1 enabled flag (0=disabled, 1=enabled) (default is disabled)
TlmChannel1FrameCount	Fixed	Channel 1 frames transmitted count
TlmCUCpfield	Fixed	P-field for CUC time in packet header
TlmCUCpfieldextension	Fixed	P-field extension for CUC time in packet header
TlmEnabledCH1	Fixed	Flag to start/stop serial channel 1
TlmEnabledCH2	Fixed	Flag to start/stop serial channel 2
TlmInterval3	Fixed	Interval for automatic sending of VCDUs on physical channel 3
TlmOutputFormat	Fixed	Flag to change output format (0=IP, 1=serial)
TlmPktDropCnt	Fixed	Used to check if any VCDU packets were dropped
TransmitCLCW	Fixed	CLCW enabled flag (0=disabled, 1=enabled) (default is disabled)
CLCWInterval	Fixed	Interval between CLCW packet transmissions in seconds
CLCWTransmitLinked	Fixed	CLCW transmission linked to H/K transmission (0=no, 1=yes) (default is linked)

SCAURA-4.1.2 Telemetry Point Container Items

Each telemetry point read from the database is defined in the container four ways. The raw value is identified by the telemetry mnemonic name or by "TLM#" followed by the parameter identification number in decimal digits. The value in engineering units is identified by one of the raw names with "_EU" added to the end. For example, the raw value for telemetry point COM_BR_TXB (parm_id=3525) may be accessed with the name "COM_BR_TXB" or "TLM#3525". Its engineering value is identified by "COM_BR_TXB_EU" or "TLM#3525_EU". The value of any telemetry point can be requested using a **get** directive. The value of any telemetry point can be changed using the **set** directive. Whenever a telemetry point's value is changed, its raw and engineering values are updated using the conversion equations from the database. Set directives may also be used within scenario files.

Note: The raw values of telemetry points are stored as integers and the engineering unit values are stored as floating point values. When floating point values are assigned to raw values, the fractional portion is dropped.

SCAURA-4.1.3 Telemetry Packet Container Items

For each valid telemetry packet defined in the database, container items are created. For each APID in telemetry there are container items to hold that APID's packet. Where "<APID>" appears in the following table, substitute the APID number in 4 decimal

digits. For example, the container buffer for APID 397 is named “TlmPacket0397”. For packets that have secondary keys, substitute the APID in 4 decimal digits plus the secondary key in 4 decimal digits for the "<APID>". For example, the container buffer for APID 114 with secondary key of 55, is named "TlmPacket01140055".

Name	Type	Description
TlmPacket<APID>	Buffer	Buffer for specified APID's telemetry packet.
TlmPacket<APID>SequenceCount	Fixed	Sequence count for APID's packet header
TlmPacket<APID>SequenceFlag	Fixed	Sequence flag for APID's packet header
TlmPacket<APID>APID	Fixed	APID for packet header
TlmPacket<APID>SecondaryHeaderFlag	Fixed	Secondary header flag for APID's packet header
TlmPacket<APID>DataLength	Fixed	Data length for APID's packet header
TlmPacket<APID>Version	Fixed	Version for APID's packet header
TlmPacket<APID>Type	Fixed	Type for APID's packet header
TlmPacket<APID>Enabled	Fixed	Enabled flag for packet (0=no, 1=yes) (default is not enabled)
TlmPacket<APID>Interval	Fixed	Time between transmissions in seconds

SCAURA-4.1.4 Telemetry Dump Packet Container Items

The dump packets are not generated from the database. In order to simulate a dump, the following dump parameters must be set. As soon as the dump word count is given, the dump packets will be formatted and transmitted until all of the specified words have been dumped. The dump word buffer may be set by a series of setBuffer directives. The dump header information may be set using directives or the “Initiate Dump Packets...” selection from the Telemetry Menu.

Command load processing optionally copies the first segment of data words in a command load to the telemetry dump data buffer. As long as successive command loads contain consecutive memory locations, data words will be copied. Event messages produced during command load processing will provide information for starting a telemetry dump of the loaded memory locations.

Name	Type	Description
CmdLoadCopyToDump	Fixed	Automatic copying of command load buffer to telemetry dump buffer enabled flag (0=disabled, 1=enabled) (default is enabled)
CmdLoadValidChecksum	Fixed	Flag for validating command load buffer's checksum (0=disabled, 1=enabled) (default is enabled)
DumpMemoryAddress	Fixed	Memory address expected for next

		consecutive command load
DumpMemoryPosition	Fixed	Current byte position for automatic copy into the telemetry dump data buffer
CmdSpaceLoadBuffer	Buffer	Spacecraft memory load buffer (1024 bytes)
TlmDumpAPID	Fixed	Dump packet APID
TlmDumpInterval	Fixed	Interval in milliseconds between dump packets: 10000 = 10 seconds, defaults to 1000 (1 second)
TlmDumpPacketSize	Fixed	Size of dump packet default is 256
TlmDumpSecondaryHeader	Fixed	0 = no secondary header 1 = secondary header with CUC
TlmDumpStartAddress	Fixed	Starting memory dump address
TlmDumpWordCount	Fixed	Number of 16 bit words to dump
SCMemory	Buffer	6000 byte telemetry dump data buffer

SCAURA-4.1.5 Telemetry VCDU Container Items

For the transmission of serial mode telemetry, certain VCDU Primary Header field values are defined in container items so that they may be easily changed. These are listed in the following table. All Aura telemetry is normally transmitted on virtual channel 2. Modification of the Fill VCDU (Virtual Channel 63) is not possible. To set the replay flag, for example, enter the directive ‘set vcdu2replay 1’.

Name	Type	Size	Description
vcdu2version	Fixed	2 bits	Version Number
vcdu2scid	Fixed	8 bits	Spacecraft ID
vcdu2vcid	Fixed	6 bits	Virtual Channel ID
vcdu2replay	Fixed	1 bit	Replay Flag
vcdu2reserved	Fixed	7 bits	Reserved Flags

It is also possible to inject data values into VCDU headers that will appear as intermittent errors in the data stream. There are 50 internal buffers where VCDUs are constructed. To inject an error that will appear once in every 50 VCDUs, enter a set directive using one of the following container names as the argument. Where “<buffer>” appears in the following table, substitute a buffer number between zero and 49. For example, the container item for buffer 11’s Primary Header Version field is named “VCDUVVERSION11”.

Name	Type	Size	Description
VCDUVVERSION<buffer>	Fixed	2 bits	Version Number
VCDUSCID<buffer>	Fixed	8 bits	Spacecraft ID
VCDUVCID<buffer>	Fixed	6 bits	Virtual Channel ID
VCDUREPLAY<buffer>	Fixed	1 bit	Replay Flag
VCDURESERVED<buffer>	Fixed	7 bits	Reserved Flags

SCAURA-4.2 Command Container Items

The container items for the command processing fall into several groups: mission specific items, validation/debug flags, CLCW fields, processing buffers, command triggering scenarios, command submnemonics and counts. Initial values for some items are shown in parentheses following the description.

SCAURA-4.2.1 Mission Specific Container Items

The initial values for these items are shown in parentheses. Values may be changed using **set** or **setBuffer** directives from the directive line or from a scenario file.

Name	Type	Description
CmdCltuCodeblockSize	Fixed	Codeblock size in bytes (8)
CmdCltuExpectedStartSequence	Buffer	Expected CLTU start sequence buffer (2 bytes) ($EB90_{16}$)
CmdCltuExpectedTailSequence	Buffer	Expected CLTU tail sequence buffer (8 bytes) ($C5C5\ C5C5\ C5C5\ C579_{16}$)
CmdCriticalTieAVCID	Fixed	Virtual Channel ID (VCID) for TIE-A critical commands (16)
CmdCriticalTieBVCID	Fixed	Virtual Channel ID for TIE-B critical commands (17)
CmdSCID	Fixed	Spacecraft Identifier (CC_{16})
CmdSlidingWindowSize	Fixed	FARM-1 Sliding Window Size (180)

SCAURA-4.2.2 Command Validation/Debug Flags

Name	Type	Description
CmdEnabled	Fixed	Command processing enabled flag. (0=disabled, 1=enabled) (default is enabled)
CodeblockValidation	Fixed	Command codeblock parity validation enabled flag. (0=disabled, 1=enabled) (default is enabled)
FrameValidation	Fixed	Command transfer frame header validation enabled flag. (0=disabled, 1=enabled) (default is enabled)
FARMValidation	Fixed	Command Frame Acceptance and Reporting Mechanism (FARM) validation enabled flag. (0=disabled, 1=enabled) (default is enabled)
PacketValidation	Fixed	Command packet validation enabled flag. (0=disabled, 1=enabled) (default is enabled)
CmdDebugEnabled	Fixed	Command master debug messages flag. (0=disabled, 1=enabled) When enabled, additional event messages are generated throughout command ingest processing. (default is disabled)
CmdDebugCLTU	Fixed	CLTU debug messages flag (0=disabled,

		1=enabled) When enabled, CLTU debug event messages are produced. This is a subset of the CmdDebugEnabled messages. (default is disabled)
CmdDebugCodeblock	Fixed	Codeblock debug messages flag (0=disabled, 1=enabled) When enabled, codeblock debug event messages are produced. This is a subset of the CmdDebugEnabled messages. (default is disabled)
CmdDebugFrame	Fixed	Frame debug messages flag (0=disabled, 1=enabled) When enabled, frame debug event messages are produced. This is a subset of the CmdDebugEnabled messages. (default is disabled)
CmdDebugSpacePacket	Fixed	Debug spacecraft packet messages flag (0=disabled, 1=enabled) When enabled, debug event messages are produced for each spacecraft channel packet. This is a subset of the CmdDebugEnabled messages. (default is disabled)
CmdDebugInstrPacket	Fixed	Debug instrument packet messages flag (0=disabled, 1=enabled) When enabled, debug event messages are produced for each spacecraft channel packet. This is a subset of the CmdDebugEnabled messages. (default is disabled)

SCAURA-4.2.3 Command Link Control Word Fields

Name	Type	Description
CmdSpaceClcwCWT	Fixed	Spacecraft CLCW Control Word Type
CmdSpaceClcwVersion	Fixed	Spacecraft CLCW Version
CmdSpaceClcwStatus	Fixed	Spacecraft CLCW Status
CmdSpaceClcwCOP	Fixed	Spacecraft CLCW COP In Effect (1)
CmdSpaceClcwVCID	Fixed	Spacecraft CLCW VCID (0)
CmdSpaceClcwSpare1	Fixed	Spacecraft CLCW Spare field 1
CmdSpaceClcwNoRFAvail	Fixed	Spacecraft CLCW No RF Avail Flag
CmdSpaceClcwNoBitLock	Fixed	Spacecraft CLCW No Bit Lock Flag
CmdSpaceClcwLockout	Fixed	Spacecraft CLCW Lockout Flag
CmdSpaceClcwWait	Fixed	Spacecraft CLCW Wait Flag
CmdSpaceClcwRetransmit	Fixed	Spacecraft CLCW Retransmit Flag
CmdSpaceClcwFarmCount	Fixed	Spacecraft CLCW Farm-B Counter
CmdSpaceClcwSpare2	Fixed	Spacecraft CLCW Spare field 2
CmdSpaceClcwReport	Fixed	Spacecraft CLCW Report Value
CmdInstrClcwCWT	Fixed	Instrument CLCW Control Word Type
CmdInstrClcwVersion	Fixed	Instrument CLCW Version

CmdInstrClcwStatus	Fixed	Instrument CLCW Status
CmdInstrClcwCOP	Fixed	Instrument CLCW COP In Effect (1)
CmdInstrClcwVCID	Fixed	Instrument CLCW VCID (1)
CmdInstrClcwSpare1	Fixed	Instrument CLCW Spare field 1
CmdInstrClcwNoRFAvail	Fixed	Instrument CLCW No RF Avail Flag
CmdInstrClcwNoBitLock	Fixed	Instrument CLCW No Bit Lock Flag
CmdInstrClcwLockout	Fixed	Instrument CLCW Lockout Flag
CmdInstrClcwWait	Fixed	Instrument CLCW Wait Flag
CmdInstrClcwRetransmit	Fixed	Instrument CLCW Retransmit Flag
CmdInstrClcwFarmCount	Fixed	Instrument CLCW Farm-B Counter
CmdInstrClcwSpare2	Fixed	Instrument CLCW Spare field 2
CmdInstrClcwReport	Fixed	Instrument CLCW Report Value

SCAURA-4.2.4 Command Container Buffers

Name	Type	Description
CmdPolyRemainderTbl	Buffer	Polynomial remainder table for parity calculation. (256 bytes)
CmdSpaceCLCW	Buffer	Spacecraft virtual channel CLCW buffer (4 bytes)
CmdInstrCLCW	Buffer	Instrument virtual channel CLCW buffer (4 bytes)
CmdSpacePkt	Buffer	Spacecraft command packet buffer (128 bytes)
CmdInstrPkt	Buffer	Instrument command packet buffer (128 bytes)
CmdFrameBuffer	Buffer	Command transfer frame buffer (256 bytes)
CmdCLTU	Buffer	Command link transmission unit buffer (6000 bytes)
CmdCodeblock	Buffer	Compressed codeblock buffer (holds codeblock bytes without parity bytes) (6000 bytes)

SCAURA-4.2.5 Command Triggering Scenarios Container Items

Name	Type	Description
ScenarioPath	String	Full pathname of directory where the command triggering scenario definition file can be found. Path should end with slash character.
ReadScenFile	Fixed	Whenever a set directive accesses this flag, the command triggering scenario definition file is re-read, replacing the previous definitions.

SCAURA-4.2.6 Command Submnemonic Container Items

For each variable command in the database, container items are created for each submnemonic field. The format for the names of these items is subname#parm_id. For example, the value received in the ANGLE submnemonic for the command with PARM_ID 32081 will be stored in "ANGLE#32081". During run-time as variable commands are identified in the database, event messages display each command's mnemonic name, its parameter ID in decimal digits, and any submnemonic names and

values. At the same time that the event message is being created, the received submnemonic values are stored into their associated container items.

SCAURA-4.2.7 Command Counter Container Items

Name	Type	Description
TIE_A_Active	Fixed	Flag indicates whether TIE A or TIE B is online for the purpose of counting codeblocks (0=TIE B, 1=TIE A) (default is TIE_A)
CmdCounter0	String	Name of telemetry point counter for TIE A valid codeblocks
CmdCounter1	String	Name of telemetry point counter for TIE B valid codeblocks
CmdCounter2	String	Name of telemetry point counter for VCID 16 valid critical commands
CmdCounter3	String	Name of telemetry point counter for VCID 17 valid critical command
CmdCounter4	String	Name of telemetry point counter for valid ISC commands
CmdCounter5	String	Name of telemetry point counter for valid PC commands
CmdCounter6	String	Name of telemetry point counter for valid GNCC commands
CmdCounter7	String	Name of telemetry point counter for valid CTC online commands
CmdCounter8	String	Name of telemetry point counter for valid CTC offline commands
CmdCounter9	String	Name of telemetry point counter for invalid ISC commands
CmdCounter10	String	Name of telemetry point counter for invalid PC commands
CmdCounter11	String	Name of telemetry point counter for invalid GNCC commands
CmdCounter12	String	Name of telemetry point counter for invalid CTC online commands
CmdCounter13	String	Name of telemetry point counter for invalid CTC offline commands
CmdTotalCLTUs	Fixed	Count of all CLTUs received
CmdValidCLTUs	Fixed	Count of valid CLTUs
CmdRejectCLTUs	Fixed	Count of invalid CLTUs
CmdTotalCodeblocks	Fixed	Count of all Codeblocks
CmdValidCodeblocks	Fixed	Count of valid Codeblocks
CmdRejectCodeblocks	Fixed	Count of invalid Codeblocks
CmdTotalTransferFrames	Fixed	Count of all Transfer Frames
CmdValidTransferFrames	Fixed	Count of valid Transfer Frames
CmdErrorTransferFrames	Fixed	Count of invalid Transfer Frames

CmdADFrames	Fixed	Count of Type AD Transfer Frames
CmdACFrames	Fixed	Count of Type AC Transfer Frames
CmdBCFrames	Fixed	Count of Type BC Transfer Frames
CmdBDFrames	Fixed	Count of Type BD Transfer Frames
CmdTotalSpacePkts	Fixed	Count of all Spacecraft Packets
CmdValidSpacePkts	Fixed	Count of valid Spacecraft Packets
CmdErrorSpacePkts	Fixed	Count of invalid Spacecraft Packets
CmdTotalInstrPkts	Fixed	Count of all Instrument Packets
CmdValidInstrPkts	Fixed	Count of valid Instrument Packets
CmdErrorInstrPkts	Fixed	Count of invalid Instrument Packets
CmdIgnoredCLTUs	Fixed	Number of CLTUs ignored while command processing is disabled.

SCAURA-4.3 Database Container Items

Name	Type	Description
DatabaseCmdConnected	Fixed	Command processing connected flag (0=not connected, 1=connected)
DatabaseCmdId	Fixed	Command identification flag (0=off, 1=on). When this flag is on, command identification using the database occurs with each received command. If command processing is too slow, this flag should be set to off.
DatabaseDebug	Fixed	Debug flag (0=disabled, 1=enabled). When enabled, database debug messages are written to the server window. (default is disabled)
DatabaseTlmConnected	Fixed	Telemetry initialization connected flag (0=not connected, 1=connected)
DatabaseVersionFound	Fixed	Version found flag (0= not found, 1=found)
TelemetryLoaded	Fixed	Telemetry loaded from database flag (0=not loaded, 1=loaded)

SCAURA-5.0 Displays

To access the displays for this module, first click on the center of the SCAURA module in the project window. The following items will appear in a pop-up menu.


Module Pop-Up Menu Item	Description
Configure	Access the configuration menu for the module
Run-time	Access the Run-time menu for the module
Remove	Remove module from the project
About	Display generic module information

SCAURA-5.1 Configuration Menu

The configuration menu for the SCAURA module contains two items.

Configuration Menu Item	Description
Load Database	Load the database information
Select Simulation Mode	Select IP or Serial Mode

SCAURA-5.1.1 Load Database




This display is used to specify the database to use to initialize telemetry information in the simulator. During run-time, this database will be accessed to identify received commands and generate event messages with command mnemonics. The Username and Password fields must be entered. When the **Apply** button is used, an attempt is made to access and read from the database.

Information about the success or failure of the database connection and telemetry initialization is reported to the event message log region.

Load Database Field	Description
Version	Optionally specifies a database version. If this field is left blank, the most recently loaded database will be used.
Username	Specifies the user account
Password	Specifies the password for the user account
Host	Optionally specifies a remote database host system. Both the local and remote systems must be properly configured to support remote database access. Refer to delivery package special operating instructions for more information. When this field is left blank, the local database is accessed.

SCAURA-5.1.2 Select Simulation Mode



This display is used to set the Simulation Mode. Depending on the simulation mode, different output interface modules must be used in the project's design. Clicking the **Apply** button causes the action defined by the fields to take effect. Clicking the **Close** button closes the window with no additional action taken.


Mode Field	Description
IP Mode	The module will use IP protocol for the output channels. See the IP module chapter for configuration of the Output IP modules.
Serial Mode	The module will use a serial output channel. See the Serial module chapter for configuration of the Serial Output module.

SCAURA-5.2 Run-time Menu

The Run-time menu for the SCAURA module contains the following three items.

Run-time Menu Item	Description
Control	Request the module's main display
Resume	Resume the module's execution
Pause	Pause the module's execution

SCAURA-5.2.1 Main Display



This is the main display for the SCAURA module, providing basic information about its current state, including the current GMT and spacecraft times, the number of valid spacecraft and instrument commands received, and the enabled/disabled status of command receipt and telemetry transmission. The latter are indicated by colored diagonal stripes around the appropriate box: the entire command box for command status and the telemetry channel boxes for each telemetry channel. Red stripes angling up and to the right indicate disabled, while green stripes angling down and to the right indicate enabled. When the module is using IP mode, the telemetry region buttons **H/K** and **CLCW** are available and the **SRL** button is unavailable. When the module is using serial mode, only the **SRL** button is available. Clicking on the **Telemetry**, **Command**, and **Time** buttons in the main window provides access to subordinate displays.

SCAURA-5.2.1.1 Telemetry Menus

There are four buttons in the telemetry area of the main display: **Telemetry**, **H/K**, **CLCW** and **SRL**. Clicking the **Telemetry** button brings up a menu with the following items.

Telemetry Menu Item	Description
Modify Packet...	Modify packet data area on byte basis
Display Packet...	Display packet header and contents
Display Status	Display status of the telemetry channels
Control Packet...	Change the frequency of the packet transmission
Initiate Dump...	Set parameters to initiate dump packets
Display/Set Container Items...	Display and optionally modify container items
Display Container Buffer...	Display any container buffer
Modify CUC...	Modify the CCSDS Unsegmented Time Code

Display APID Status	Display status of database defined packets
---------------------	--


Clicking the **H/K**, **CLCW** or **SRL** channel buttons brings up a menu with the following choices.

Channel Menu Item	Description
Start	Enable telemetry transmission on the channel
Stop	Disable telemetry transmission on the channel

Note: The **H/K** and **CLCW** buttons have been linked together to simplify operations. Whenever the **H/K** button is used to start or stop housekeeping telemetry transmission, the same action will be applied to the CLCW channel. The **CLCW** button may be used to start or stop the CLCW channel independently as well. If decoupling of these two buttons is desired, enter the following directive on the directive line or scenario file.

Set ClcwTransmitLinked 0

SCAURA-5.2.1.1.1 Modify Packet Display



This display allows the user to modify the data area of the packet on a byte or repeating byte basis. All of the display fields must be entered.


Data Entry Field	Description
APID	Application ID of the packet to be modified
Start Byte	First byte to change
Stop Byte	Last byte to change
Value (Hex)	Value to change byte(s) to, in hexadecimal

SCAURA-5.2.1.1.2 Telemetry Packet Display



The telemetry packet display shows the header and, optionally (by pressing the **Dump** button), the contents of the most recent telemetry packet sent with the given APID. The user must enter a valid value in the APID field and then click the **Apply** button before any other values will be reported. If there are multiple formats for an APID, click the

“Use Secondary Key” box and enter the secondary key value in the space next to the APID. Clicking the **Dump** button will bring up a standard dump display with the contents of the packet. Clicking the **Edit** button will bring up the Modify Tlm Packet Header Display shown below. Clicking the **Close** button closes the window with no additional action taken.



The Modify Tlm Packet Header display allows the user to modify fields in the packet header. Click on an enable box to the left of the field to enable modification of a specific header field. Clicking the **Apply** button puts the settings into effect. Clicking the **Close** button closes the display with no additional action taken.

The purpose of the Modify Tlm Packet Header display is to inject data values into transmitted packets that could be perceived as erroneous by the receiving system. Changing the APID and Pkt Len fields does not change the name or length of the buffer, only the data in the header fields.


Data Entry Field	Description
Version	CCSDS packet version number
Type	CCSDS packet type
SH Flg	Secondary header flag
APID	Application identifier (packet number)
Seq Flg	Sequence flag
Seq Cnt	Packet sequence counter
Pkt Len	Packet length for data zone (seven less than actual length)

SCAURA-5.2.1.1.3 Telemetry Status Display



The telemetry status display shows the enabled or disabled status and the number of packets transmitted for each of the two telemetry channels. Clicking the **Reset** button will reset the count of packets transmitted for that channel. Clicking the **Close** button closes this window with no additional action taken.


SCAURA-5.2.1.1.4 Control Packet Display



This display allows the user to control whether or not a telemetry packet is generated and optionally change the rate at which it is transmitted. Clicking the **Apply** button puts the settings into effect. Clicking the **Close** button exits the display.

Data Entry Field	Description
APID	Application ID of the packet to be modified
Enable	If flag is set, packet is formatted and sent
Disable	If flag is set, the packet is not transmitted
Change Rate	This box must be checked in order to change the rate field


SCAURA-5.2.1.1.5 Initiate Dump Packets



This display allows the operator to specify dump packet header values and initiate the sending of dump packets. The dump data words are kept in the container buffer SCMemory. This buffer may be modified using the setBuffer directive on the directive line or within a scenario file. As soon as the “Number of Words” field has been specified, the dump packets are formatted and transmitted until the requested number of words have been dumped. Only one dump may be specified at a time.

Data Entry Field	Description
Packet APID	Application ID to store in dump packet header
Packet Length	Maximum size of dump packet. The last packet may be smaller.
Interval	Time between dump packet transmissions, in milliseconds
Start Address	Starting memory address
Number of Words	Number of words to be dumped
Dump Secondary Header	If this box is checked, the dump packets will have a secondary header containing a CCSDS unsegmented time code. If this box is not checked, the dump packets will not have a secondary header.

SCAURA-5.2.1.1.6 Display/Set Container Items



This display allows the user to view and modify individual items from the SCAURA module's container. Since telemetry points are stored as container items, telemetry points may be monitored and overwritten with this display. The first two items in the sample screen are telemetry points. To request an item for display or editing, enter its name in the mnemonic field and click the **Apply** button. If there are any problems with displaying or modifying items, error messages are sent to the event message area of the screen.


Multiple copies of this display are allowed, but each container item should only appear on one screen for properly updated values.

Field	Description
Checkbox	Click on this box to modify an item's value.
Mnemonic	This field identifies a container item for display. Refer to section "SCAURA-4.0 Container Items" for the container names of specific items. This field is not case-sensitive.
Value	If the associated checkbox is not checked, this is the current decimal value of the container item. If the checkbox is checked, this is a data entry field for the value of the item.

SCAURA-5.2.1.1.7 Display Container Buffer


This display may be used to display container buffers that do not have a customized display available for them. Enter the buffer name, offset, size and count and click on the **Apply** button. If there are problems displaying a buffer, error messages are sent to the event message area of the screen.

If the buffer's contents are updated frequently, the **Pause** button may be used to display a "snapshot" of the buffer. (Buffer contents will continue to be updated offscreen.) The button's name is changed to **Cont**. To resume updates of the buffer, press the **Cont** button. Only one copy of this display may be active at a time. When switching from the display of one buffer to another, it may be helpful to toggle the **Pause/Cont** button on and off to force a refresh of the buffer contents.



Field	Description
Buffername	This field identifies the container buffer for display. Refer to section "SCAURA-4.0 Container Items" for names of container buffers.
Offset	This field specifies the first byte to be displayed. This display is limited to 1400 data bytes at a time. This field is used with the count field to specify the portion of the buffer to display.
Size	Size of the data items to display (choices are byte, word, double)
Count	Number of data items to display (limited to 1400 total characters)
Addr Mode	Addresses of the data may be displayed in hexadecimal or decimal
Data Mode	Data may be displayed in hexadecimal or octal formats

SCAURA-5.2.1.1.8 Modify CCSDS Unsegmented Time Code



This display allows the user to modify the fixed fields of the CCSDS Unsegmented Time Code (CUC) in the telemetry packet headers. Clicking the enable boxes at left indicate whether or not the given field should be modified. Clicking the **Apply** button puts the settings into effect.

Data Entry Field	Description
P-field	P-field flags in the CUC. Enter hexadecimal value.

P-field Extension	Second byte of p-field, containing number of leap seconds since 1958. Enter hexadecimal value.
-------------------	--

SCAURA-5.2.1.1.9 Display APID Status


This dynamically updating display provides a scrollable list of the current status of all telemetry packets created from the project database. The first column provides the APID number in decimal. Next the word "disabled" or "ENABLED" is displayed. The last column provides the interval between packet transmissions in seconds.

The display's updating may be interrupted by clicking on the **Pause** button. The button's title will change to **Cont**. Click on the **Cont** button to resume status updates. Use the **Close** button to dismiss the display.

The "Control Packet..." telemetry menu item may be used to modify any packet's status. Directives or scenario files may also be used to change packet status. The container names for these fields are TlmPacket<APID>Enabled and TlmPacket<APID>Interval, where the <APID> portion is replaced with the packet's APID in 4 decimal digits. For example, the following directives change the interval of packet 220 to 8 seconds and enable its transmission.

```
set TlmPacket0220Interval 8.0
```

```
set TlmPacket0220Enabled 1
```




SCAURA-5.2.1.2 Command Menu

Clicking the **Command** button on the main display brings up the command menu.


Menu item	Description
Start	Enable command reception
Stop	Disable command reception
Display Status...	Enable/disable status, command counts, CLCWs by virtual channel
Modify Validation Criteria...	Allows modification of validation options
Display Spacecraft Packet...	Displays spacecraft virtual channel packet contents
Display Instrument Packet...	Displays instrument virtual channel packet contents
Override CLCWs	Edit the fields of the Command Link Control Words
Display Spacecraft Load...	Display the Spacecraft Memory Load Buffer

SCAURA-5.2.1.2.1 Display Command Status



When the “Display Status...” option is selected, this display is shown. The command status display shows command counters, command enabled or disabled status and the Command Link Control Words (CLCWs) for the spacecraft and instrument virtual channels. Clicking the **Reset** button sets the counter in that row to zero.

SCAURA-5.2.1.2.2 Modify Validation Criteria



When the “Modify Validation Criteria” option is selected, this screen is displayed. The operator may select any combination of the validation options. The operator may enable all of the validation tests by selecting the “All” option or disable all of the validation tests by selecting the “None” option. The **Apply** button is used to activate the new settings. The **Close** button is used to dismiss the screen without changes.

SCAURA-5.2.1.2.2.1 None Validation Option

Even when the “None” option is selected the following validation tests are performed.

- A received CLTU must be long enough to contain a start sequence, a single codeblock, and a tail sequence or it will be rejected and an error event message will be generated.
- A CLTU’s length will be checked to see there are enough bytes for a start sequence, tail sequence, and an even multiple of codeblocks. If there are extra bytes, they will be reported in a warning event message. The CLTU will then be processed as if there were no extra bytes. The existence of “extra” bytes may indicate a problem with the source system’s formatting of the CLTU.
- The transfer frame header length field must report a value big enough to contain a transfer frame header and a single byte of data or it will be rejected and an error event message will be generated.
- The transfer frame header length field is compared to the actual length of the passed frame buffer. If there are more data bytes than are reported in the header, these bytes are compared to the fill data byte. If there are any “extra” bytes that are not fill data, a warning event message will be generated. The transfer frame will then be processed and the “extra” bytes will be ignored. The existence of “extra” non-fill bytes may indicate a problem with the source system’s formatting of the Transfer Frame.
- The transfer frame header VCID is used to determine whether the frame should be processed as a critical TIE command or passed to the spacecraft or instrument virtual channel Frame Acceptance and Reporting Mechanism (FARM). The VCID must match one of the four expected VCID values stored in the container. When a VCID does not match any of the expected values, the transfer frame is rejected and an error event message is generated.

SCAURA-5.2.1.2.2.2 Validation of CLTU Start and Tail Sequences

Since a received CLTU must contain a valid start and tail sequence to be recognized by

the software, disabling validation of these items is not an option. Rather, the software will report appropriate event error messages if the start sequence cannot be located, or if the start sequence is located but the tail sequence is not found.

SCAURA-5.2.1.2.2.3 BCH Error Code Validation Option

When Bose-Chaudhuri-Hocquenghem (BCH) Error Code validation is enabled, the parity byte of each received codeblock is compared to the parity value calculated from the codeblock data area. If a parity comparison fails, both parity bytes are reported in an error event message and the current CLTU is rejected.

SCAURA-5.2.1.2.2.4 Transfer Frame Header Validation Option

When transfer frame validation is enabled, the following validations are done.

- The transfer frame header version field must contain 0 or the frame is rejected and an error event message is generated.
- The transfer frame header spare field must contain 0 or the frame is rejected and an error event message is generated.
- The transfer frame header length is tested to be within the range specified in the ICD. If the length is invalid, the “Incorrect Frame Length” status is stored in the CLCW, the frame is rejected, and an error event message is generated.
- The transfer frame header length is compared to the actual length of the received buffer. If the frame contains fewer bytes than reported in the header, the “Incomplete Frame” status is stored in the CLCW, the frame is rejected, and an error event message is generated.
- The transfer frame header mode flags are checked. If the mode is “AC”, the “Illegal frame type (Type-AC)” status is stored in the CLCW, the frame is rejected, and an error event message is generated.
- If the transfer frame header mode flags specify “BC”, the frame data is checked for a valid transfer frame control command. If the frame data does not contain a valid frame control command, the “Illegal Type-BC frame” status is stored in the CLCW, the frame is rejected, and an error event message is generated.
- The transfer frame header VCID field is compared to the VCID field from the FARM’s CLCW. If the VCID fields do not match, the “Illegal VCID” status is stored in the CLCW, the frame is rejected, and an error event message is generated.
- If the transfer frame header SCID field does not match the Aura SCID stored in container point CmdSCID, the “Illegal SCID” status is stored in the CLCW, the frame is rejected, and an error event message is generated.

SCAURA-5.2.1.2.2.5 Farm (Valid Frame Sequence) Validation Option

When FARM validation is enabled, the transfer frame header sequence field is subjected to the FARM-1 protocol and the CLCW flags, FARM-B Counter, and Report Value fields will be updated accordingly. Event messages are generated for every transfer


frame that fails the acceptance test.

SCAURA-5.2.1.2.6 User Command Packet Header Validation Option

When packet validation is enabled, fields in the packet header will be validated as specified in the EOS Aura Spacecraft to Ground ICD.

SCAURA-5.2.1.2.3 Display Spacecraft Packet

This display shows the spacecraft virtual channel command packet header. A dump of the full packet buffer may be requested by pressing the **Dump** button.



The Dump address region may be displayed in decimal or hexadecimal. The data region may be displayed in hexadecimal or octal. Since this display normally updates as the buffer contents are changed, use the **Pause** button to freeze the current contents. Use of the **Pause** button does not affect command packet reception. When the **Pause** button has been used, the button's label is changed to **Cont** (for continue). Press the **Cont** button to resume screen updates. Note that the display is updated to show the last command packet received. Intermediate packets received while the display was frozen can not be displayed.

SCAURA-5.2.1.2.4 Display Instrument Packet

This display shows the instrument virtual channel packet header. Optionally, a dump of the full packet buffer may be requested. They are very similar in appearance and function to the spacecraft packet header and packet dump displays that are described in the previous section.

SCAURA-5.2.1.2.5 Override CLCWs


This display shows the Command Link Control Words (CLCWs) for the two virtual channels broken out into bit fields. Any field may be overridden by checking the field's selection box and then typing in the new decimal value. The new value takes affect when the **Apply** button is pressed. Note that since these are bit fields, attempts to assign values that are too large will result in truncation of the value. Review changes on the CLCW portion of the Command Status display. Event messages also show the values assigned.



CLCW Field	Description
CWT	Control Word Type (1 bit)
VER	Version (2 bits)
STAT	Status (3 bits)
COP	Command Operations Procedure (COP) in Effect (2 bits)
VCID	Virtual Channel Identification (6 bits)
SP1	Spare field 1 (2 bits)
RF	No RF Available Flag (1 bit)
BITLCK	No Bit Lock (1 bit)
LCKOUT	Lockout Flag (1 bit)
WAIT	Wait Flag (1 bit)
RETRANS	Retransmission Flag (1 bit)
FARMB	FARM-B Counter (2 bits)
SP2	Spare field 2 (1 bit)
REPVAL	Report Value (8 bits)

SCAURA-5.2.1.2.6 Display Spacecraft Load


When the “Display Spacecraft Load...” option is selected, the buffer containing the accumulated spacecraft load packet data is displayed.



SCAURA-5.2.1.3 Time

The time area of the main display shows the current Greenwich Mean Time (GMT) and spacecraft time fields. The GMT is a reflection of the simulated time of the SCAURA module, i.e., what time will be used to model external events (transitions to day or night, for example) within the module. It is not currently used. The spacecraft time is the time that the spacecraft thinks it is. In particular, it is the time (in the appropriate format) that goes into the secondary header of the telemetry packets generated by the SCAURA module. Clicking the **Time** button brings up a menu with one selectable item, “Modify Times...”.

SCAURA-5.2.1.3.1 Modify Times Display



This display allows the user to set the GMT or spacecraft time manually, retain the time currently being used, or reset the time to the current system time.

Clicking the **Apply** button will cause the requested actions to take effect.

Clicking the **Close** button closes the window with no further action taken.

Field	Description
yyyy	Year
ddd	Day of year
hh	Hour of day
mm	Minute of hour
ss	Second of minute
Keep	Don't update time
Reset	Change time to current system time
Set	Set time to value supplied

SCAURA-5.3 Remove

Clicking the “Remove” option from the module pop-up menu causes this module to be removed from the project. This option is not available during run-time.

SCAURA-5.4 About

Clicking the “About” option from the module pop-up menu requests a display that lists generic information about the module such as the numbers of input and output channels.

SCAURA-6.0 Special Operating Instructions

SCAURA-6.1 Serial Mode Operation

In order to run the SCAURA module in serial mode select serial mode from the Select Simulation Mode Display during project configuration. SCAURA output channel 3 must be linked to a serial output module. A serial I/O card is required on the server platform.

SCAURA-6.2 Triggering Scenarios with Commands

A powerful feature of the SCAURA module is to be able to automatically trigger the execution of specified scenario files when specific commands are recognized from the database. The project must contain a scenario module. The output channel from the scenario module must be connected to input channel 1 of the SCAURA module.

SCAURA-6.2.1 Using the Default Scenario Directory

Create a file named **Command-Scenario.txt** in the release's scenario directory. (The scenario directory should be at the same level as the properties, elog and save directories.) The scenario files to be executed should be placed in this directory. The command trigger definition file is read immediately after the database is loaded. The trigger information is stored in memory. Event messages will be generated for any invalid command mnemonics and any invalid scenario filenames in the definition file.

Format of Command-Scenario.txt File

Command-scenario pairs are specified by the following format:

```
command mnemonic | scenario filename
```

One pair is specified per line with the “|” character as the delimiter. Leading and trailing spaces and tab characters will be removed so these characters may be used to align the

data. The scenario filename may be specified as a full or relative pathname. Relative pathnames will start from the scenario directory. Each command mnemonic should only appear in the definition file once.

Any line starting with a semicolon ";" in column one is ignored as a comment.

Blank lines are also ignored.

SCAURA-6.2.2 Using an Alternate Scenario Directory

If a user wishes to use an alternate set of scenario files, place them in a specific directory on the disk, for example, D:\My-Scenarios. Place the command trigger definition file, Command-Scenario.txt, in this directory as well.

Every reference to a scenario file, from within the command trigger definition file or from within a scenario file MUST use the file's fully specified path name. For example, an entry in the definition file might be:

```
CDH_EXECUTE_TIENOP | D:\My-Scenarios\tienop.txt
```

If any scenario file calls tienop.txt, the format for the calling statement within the scenario file is

```
Start scenario D:\My-Scenarios\tienop.txt
```

When the simulator is started, the default command trigger definition file will be read from the default directory. To force replacement of the default trigger information with the alternate definition file send directives similar to the following to the SCAURA module. Do not use quotes around the alternate directory name and do not forget the ending slash.

```
Set scenarioPath D:\My-Scenarios\  
Set readScenFile 0
```

These set directives must be done each time the simulator is started. To make this easier, place both directives in a scenario file in the alternate directory. After the simulator is running, use the Scenario module GUI file browser to navigate to the alternate directory and execute this file.

SCAURA-6.2.3 Update/Replace Command Trigger Definitions

During run-time the operator may request that the Command-Scenario.txt definition file be read in again replacing the previous definitions. On the directive line to the SCAURA module, enter the following. Check the event message log for status and error messages.

```
Set ReadScenFile 0
```

Internet Protocol (IP) Modules

IP-1.0 Overview

The Input and Output Internet Protocol (IP) modules receive/send data packets from/to other sources/destinations using one of several IP types (TCP/IP-Client, TCP/IP-Server, UDP Multicast, or UDP Unicast). The Input IP module receives data from an external source and passes that data to another module. The Output IP module receives data from a module and can pass that data to another module and send it to an external destination. Both the Input and Output IP modules are discussed in this one section because of their great similarity.

IP-2.0 Inputs

The Input IP module does not have any input channels. The Output IP module has a single input channel, which is listed below.

Channel	Data expected	Validation performed	Processing performed
1	Packets	None	Received data is passed to connected modules and transmitted to configured external IP destination

IP-3.0 Outputs

Both the Input IP and Output IP modules have a single output channel.

Channel	Description
1	Input IP module passes received data to all connected modules. Output IP module passes received data to connected modules (usually the Log Module) and sends it to an external destination

IP-4.0 Container Items


IP module container items are not accessible via operator directives, so they are not listed here.

IP-5.0 Displays

Click in the center of the module in the project window to access displays. The following pop-up menu will appear. The “Remove” option can be used during project design to remove this module. The “Configure” option must be used prior to running the project and is unavailable at run-time.

Module Pop-Up Menu Item	Description
Configure	Access the configuration display
Run-time	Access the Run-time menu for the module
Remove	Remove module from the project
About	Display generic module information

IP-5.1 Configuration




Clicking on the Input (or Output) IP module pop-up menu “Configure” item produces displays similar shown on the above.

IP-5.1.1 Configure IP Type Field

There are 4 possible IP Types available from a drop down menu: UDP Multicast, TCP/IP-Client, TCP/IP-Server, and UDP Unicast.

IP-5.1.2 Configure Receiver (or Sender) Address Box



Step 1. If there are more than one Ethernet Card on the host machine where the server is running, a user can select an IP address if it is sensitized from the drop down menu (similar shown on the left) as a network interface of the host machine.

Step 2. Enter a Port Number if it is sensitized to let the host machine to bind on to either receive or offer a service.

Note: The IP address **127.0.0.1** is a loopback address, it is used to test the network program in a single machine excepts UDP Multicast mode; in other words, **Don't** select **127.0.0.1** as a receiver (or sender) IP address in UDP Multicast mode.

IP-5.1.3 Configure Source (or Destined) Address Box

There are different situations for the different IP types.

For **TCP/IP-Client** of Input and Output IP modules:

Step 1. Enter 4 fields of the IP Address, it is an IP address of the server that the client attempts to connect (actually, the client will use the name address that includes IP address and port number to connect to the server).

Step 2. Enter a Port Number, it is a port where the server offers a service on.

For **TCP/IP-Server** of Input and Output IP modules:

A user is not allowed to configure this box (4 fields of IP address and 1 field of Port Number are desensitized).

For **UDP Unicast** of Output IP module:

Step 1. Enter 4 fields of the IP Address, it is a destination IP address of the remote host where the packets will be sent (actually, a destination name address that includes destination IP address and port number).

Step 2. Enter a Port Number, it is a port where the packets will be sent.

For **UDP Unicast** of Input IP module:

A user is not allowed to configure this box (4 fields of IP address and 1 field of Port Number are desensitized).

For **UDP Multicast** of Input IP module:

Enter 4 fields of the Multicast Group Address, it is a multicast group address that Input IP module will join in and where the packets will be received.

A user is not allowed to configure the field of the Port Number (it is desensitized).

For **UDP Multicast** of Output IP module:

Step 1. Enter 4 fields of the Multicast Group Address, it is a multicast group IP address where the packets will be sent (actually, a multicast group name address that includes a multicast group IP address and port number).


Step 2. Enter a Port Number, it is a port where the packets will be sent.

Note: The valid range of a port number is 1000 to 65535; the valid range of a multicast group IP address is 224.0.1.0 to 239.255.255.255.

IP-5.1.6 Configure Variable Length Input (or Output) Field

The default configuration is to process variable length fields. When this option is selected, the box is checked and the Frame size field is desensitized. When selected, the actual length of each data packet will be used, without truncation or padding.

IP-5.1.7 Configure Frame Size Field



First clear the Variable Length Input (or Output) checkbox so that the Frame size field is enabled for input. Enter the fixed size in bytes in the Frame size field.

If this size is larger than the actual data, the additional bytes will be filled with binary zero.

Note: If the configured frame size is smaller than the actual data size, the data bytes will be truncated to the specified frame size before being passed to the next module or external destination.


IP-5.2 Run-time

Click on the module pop-up menu “Run-time” option to request the Run-time Menu.

Run-time Menu Item	Description
Show Status	Request Status Display
Show Raw Packet	Request Raw Packet Display
Pause (or Resume)	Pause (or Resume) the module
Stop (or Restart)	Stop (or Restart) the module

IP-5.2.1 Show Status


Select the “Show Status” item to request the module’s status. This produces display similar to that shown below.



This display shows the Input (or Output) IP module's IP Type, Receiver (or Sender) Address (include IP address and port number), Source (or Destined) Address (include IP address or multicast group IP address and port number), Frame size, and number of packets received (or transmitted). If variable length items are being received, the Frame size field will show the most recent size. The **Reset** button may be clicked to reset the number of packets received count. Click the **Close** button to dismiss the display.

IP-5.2.2 Show Raw Packet

Select “Show Raw Packet” from the Run-time Menu to show raw packets received by the module.



The address region may be displayed in decimal or hexadecimal by clicking on the respective radio button. Likewise, the data region may be displayed in hexadecimal or octal. Since this display updates as the buffer contents are changed; the **Pause** button may be used to freeze the current contents. Use of the **Pause** button does not affect data transmission or reception. When the **Pause** button has been used, its label is changed to **Cont** for continue. Press the **Cont** button to resume screen updates. Note that the display will update with the last packet processed. Packets not shown while the display was frozen can not be displayed. Click the **Close** button to dismiss the display.

IP-5.2.3 Pause

Select “Pause” from the Run-time Menu to pause the IP module’s processing. The color around the module’s border will change from green-striped (indicates run state) to red-striped (indicates non-run state). This option’s text will be changed to “Resume”. When an Input IP is paused, a limited amount of data for it is queued up. When an Output IP module is paused, any data passed to it is dropped.

IP-5.2.4 Resume

After an individual module has been paused, select “Resume” from the Run-time Menu to resume the module’s execution. The color around the module’s border will change from red to green. This option’s text will be changed to “Pause”. The Input IP first processes any data queued up while paused. The Output IP processes new data only.

IP-5.2.5 Stop

Select “Stop” from the Run-time Menu to stop the IP module’s processing. The color around the module’s border will change from green to red. This option’s text will be changed to “Restart”. Once the module has been stopped, the “Configure” option of the module pop-up menu is available again and the module may be reconfigured. Any data passed to stopped modules is discarded.

IP-5.2.6 Restart

After an individual module has been stopped, select “Restart” from the Run-time Menu to restart the module. The color around the module’s border will change from red to green. This option’s text will be changed back to “Stop”. Since their configurations may have changed, the IP modules reset all counters and only process new data.

IP-5.3 About

Selecting the “About” option from an IP module pop-up menu produces a display that lists the module’s number of inputs and outputs, whether directives are allowed, names of authors and the version number.

IP-6.0 Special Operating Instructions

There are no special operating instructions for this release.

Log Module

Log-1.0 Overview

The Log module writes the data it receives to a specified log file.

Note: Viewing or printing of log files may be accomplished by means of an external program. The software used must be capable of displaying binary data in an ASCII representation. The shareware utility, Hexedit, which is available over the Internet from Alexander Reidel Informations-Systeme, is one such program.

Log-2.0 Inputs

Ch	Data expected	Validation performed	Processing performed
1	bytes	None	Received log data is written into the log file.

Log-3.0 Outputs

The Log module does not have any output channels.

Log-4.0 Container Items

Log module container items are not accessible via operator directives, so they are not listed here.


Log-5.0 Displays

To access displays for this module, click in the center of the Log module in the project window. The following pop-up menu choices will appear. The “Remove” option can be used during project design to remove this module. The “Configure” option should be used prior to running the project and is unavailable at run-time. The Run-time option is available only when the project is running.

Module Pop-Up Menu Item	Description
Configure	Access the configuration display
Run-time	Access the Run-time menu for the module
Remove	Remove the module from the project
About	Display Information about the module

Log-5.1 Configuration

Selecting the “Configure” pop-up menu option produces a display similar to the following screen.



Log-5.1.1 Log File Name

The Log File Name specifies where the log data is written. If this file already exists, its data will be overwritten. If there is more than one Log module in a project, they cannot write to the same log file.

Log-5.1.2 Maximum Log Size (bytes)

The Maximum Log Size in bytes limits the amount of storage used for logging. When this maximum is reached, the log file is closed and an event message is generated.

Log-5.1.3 Packet Size (bytes)

The Packet Size defines the size of the data buffer to be written to the log file. A packet size that is smaller than the actual data buffer received will result in truncation of the data that is logged. A packet size that is larger than the actual data buffer received will be zero filled to the packet size and then written to the log file.

Log-5.1.4 Log With Header

When the Log With Header box has been checked, all log records will begin with a log header of ten bytes. This header consists of eight bytes of system time followed by two bytes of data length. The following example shows two CLCW packets. The header in each packet has been circled for clarity. When the Log With Header box is unchecked, all records will be written without a header.

hexedit1															
00000000	01	BF	85	59	4F	6D	6A	A0	00	20	02	8C	8C	EA	DA
00000015	80	00	00	00	00	00	00	00	00	00	66	82	00	00	01
0000002A	01	BF	85	59	4F	7F	C0	E0	00	20	02	8C	8C	EA	DA
0000003F	80	00	00	00	00	00	00	00	00	00	66	82	00	00	02

Log-5.1.5 Variable Length Output

When the Variable Length Output box has been checked, varying length records are written to the log file. No truncation or padding of received data is done. When this field is checked, the packet size field is desensitized.


Log-5.2 Run-time

Clicking the “Run-time” option of the module pop-up menu produces a Run-time menu.

Run-time Menu Item	Description
Show Status	Request Status Display
Pause (or Resume)	Pause (or Resume) the module
Stop (or Restart)	Stop (or Restart) the module

Log-5.2.1 Show Status

When the “Show Status” option is selected from the Run-time Menu, a screen like the following is displayed. The bar in the center of the screen shows the percentage of the log area in use. The dark blue portion of the bar represents the logged data.



Log-5.2.2 Pause/Resume

Select “Pause” from the Run-time Menu to pause the Log module’s processing. The color around the module’s border will change from green (indicates run state) to red (indicates stopped state). The text of this menu option will change to “Resume”. While the Log Module is paused, it does not receive or log data.

After a Log module has been paused, select “Resume” from the Run-time Menu to restore processing. The color around the module’s border will change from red to green. The text of this menu option will change to “Pause” and the module pop-up menu will have the normal Run-Time selections.

Log-5.2.3 Stop/Restart

Select “Stop” from the Run-time Menu to stop the Log module’s processing. The color around the module’s border will change from green to red. The text of this menu option will change to “Restart”. Once the module has been stopped, the “Configure” option of the module pop-up menu is available again and the module may be reconfigured.

After a Log module has been stopped, select “Restart” from the Run-time Menu to restart the module’s execution. The color around the module’s border will change from red to green. The text of this option will change to “Stop” and the module pop-up menu will have the normal Run-Time selections.

Log-5.3 About

Selecting the “About” option from the module pop-up menu produces a display that lists the module’s number of input links, number of output links, whether directives are allowed, names of authors and the version number.

Log-6.0 Special Operating Instructions

There are no special operating instructions for this release.

Scenario (SN) Module

SN-1.0 Overview

The Scenario module reads directives from specified scenario files line by line and passes them to down-linked modules for processing. The user interface allows the operator to control and monitor the execution of up to five scenarios at a time. The scenario module may also receive scenario file names from a down-linked module. In addition, any scenario file being processed may start the execution of other scenario files.

SN-2.0 Inputs

SN-2.1 Server/Properties/Property.txt

When the project containing a scenario module is started, the server reads a property.txt file in the server's properties directory to configure several project parameters. One of these parameters, ***ConcurrentScenario***, defines how scenario modules will execute nested scenario files and module triggered scenario files.

The default setting for *ConcurrentScenario* is one. When set to one, the scenario module executes nested and external module requested scenario files concurrently. Additional system resources are dynamically allocated and released as these scenarios start and stop execution.

If the setting for *ConcurrentScenario* is zero, both types of non-GUI controlled scenario files are collected in a queue and executed in first-in-first-out (FIFO) order. This method is less taxing on system resources but may not execute scenario files quickly enough in some cases. This mode should be used if there are system resource problems over time or if the execution of scenario files causes degradation of other processing.

SN-2.2 Module Triggered Scenarios

The Scenario module does not technically have any input channels. It is not possible to create an input link to this module. Its lone output channel is actually bi-directional, providing only the down-linked module a way to pass names of scenario files to be executed. Processing specific to the down-linked module may trigger the passing of scenario file names back to the scenario module for immediate execution.

SN-2.3 Scenario File Input

Much of the input to this module is via scenario files, which are read during run-time. There are no naming conventions for scenario files. Scenario files are expected to be in the scenario directory, which is below the server executable directory, unless a full pathname is specified. Relative pathnames are assumed to start from the scenario directory.

SN-2.3.1 Scenario File Contents

The format of ASCII text scenario files is very simple. Each line is limited to 260 characters. Each line contains one of the following items. Tab characters and blanks may be used to indent scenario lines for readability. Although Scenario-module specific key words are shown below in uppercase, they are not case sensitive.

Line	Description
comment line	A semicolon in the first column defines a comment.
blank line	A line containing only blank or tab characters is treated as a comment line.
SLEEP milliseconds	The scenario module pauses execution of the file for the number of milliseconds specified. When milliseconds are specified as -1, the directive is a SLEEP forever. For a GUI controlled scenario, a sleep forever is equivalent to the pause button being used. For non-GUI controlled scenarios, the SLEEP forever instruction is ignored.
START SCENARIO name	The scenario module starts execution of a nested scenario file. This nested file runs without operator intervention even if the file that started it was operator controlled.
directive	Any line that is not a comment or processed by the scenario module is assumed to be a directive for the linked module. The receiving module performs any validation done on this line. The format for directives is the same as if the operator had entered it in the project directive entry line.
IF (expression)	Specifies the conditional expression that must be true in order for the directives following this line up to the next ELSE IF, ELSE or ENDIF statement to be executed.
ELSE IF (expression)	Specifies a conditional expression that must be true in order for the directives following this line up to the next ELSE, ELSE IF or ENDIF statement to be executed.
ELSE	Specifies the beginning of the directives to be executed when the preceding IF or ELSE IF expression is false.
ENDIF	Specifies the end of any optional ELSE clauses and the end of the current IF statement.
WHILE (expression)	Specifies the conditional expression that must be true in order for the directives following this line up to the ENDWHILE statement to be executed. One of the directives within the loop body should be a SLEEP directive.
ENDWHILE	Specifies the end of the current WHILE loop.

SN-2.3.1.1 Specifying Modules to Receive Scenario Directives

A scenario file may contain directives for more than one module. Any executable line within a scenario file may start with an optional module number field with the format:

#x <directive line text>

where x is a number from 1 to 4. A directive labeled with #2 is sent to the module(s) connected to output channel 2. Subsequent directives are also sent to channel 2 until the end of the scenario file or another channel is specified. When present, the module number must be followed a blank character. At the beginning of each scenario's execution, the module number is initialized to 1. In the absence of any module numbers, directives are sent to the module(s) linked to the scenario module's output channel 1.

SN-2.3.1.2 Specifying Conditional Expressions

The conditional expression must be specified on a single line of up to 260 characters (including the return key). The directives to be conditionally executed must be entered on separate lines from the keywords IF, ELSE, ENDIF, WHILE and ENDWHILE.

The special characters used to describe conditional expressions for IF and WHILE statements are parentheses, binary math operators (+, -, *, /, %), binary logical operators (<, <=, ==, >=, >, !=, &&, ||), unary operators (!, -) and trigonometric operators (rsin, rcos, rtan, rasin, racos, ratan, sin, cos, tan, asin, acos, atan, dtor, rtod, sqrt, ln, exp). Additional operators (such as XOR and NAND) may be used in set directives but not in conditional expression clauses.

At least one set of parentheses must be used to enclose a conditional expression. Additional sets are recommended for proper evaluation of complex algorithms. Proper matching of parentheses is very important. If any parentheses are missing, a warning event message will be generated and the conditional expression will be evaluated as false.

SN-2.3.1.3 Simple Scenario Example

The following 4 lines are a simple example of a scenario file. The first line is a comment. The second line is a directive to the Scenario module to pause for one second. The third line is a directive to the linked module to change the value of the container item named "TransmitMode" to one. The fourth line starts execution of a nested scenario file named OtherScenario.txt.

```
;This is a comment line in a scenario file
SLEEP 1000
set TransmitMode 1
Start scenario D:/Scenario/OtherScenario.txt
```

SN-2.3.1.4 IF Scenario Example

```
if ((mnemonic0 + rsin(mnemonic1)) > mnemonic2)
    set mnemonic4 321
else if (!mnemonic3)
    set mnemonic5 20
    set mnemonic6 += 100
else
    set mnemonic7 512
endif
```

SN-2.3.1.5 While Scenario Example

The following is an example of a scenario file using a while statement. A sleep delay within the loop is needed to prevent CPU-intensive wait loops.

```
while ((mnemonic0 < 5)&& (mnemonic2 > sqrt(mnemonic3)))
    set mnemonic2 -= sqrt(mnemonic3)
    set mnemonic0 += 1
    Sleep(1000);
endwhile
```

SN-3.0 Outputs

The Scenario module has 4 output channels. Each output channel should be linked to input channel 1 of the module to receive the directives.

Channel	Description
1-4	Scenario module sends the read directives to the linked module.

SN-4.0 Container Items

The Scenario module accepts operator directives and is capable of receiving directives from other SIMSS modules. Use the **Set** and **Get** directives to access items with a fixed type. Use the **SetBuffer** and **GetBuffer** directives on buffer types. Although names in the following table contain upper and lower case, directive lines are not case-sensitive.

There are 6 container items for each of the five GUI-controlled scenarios. To modify or view most of these fields, it is easier to use the Run-time Control display. To access the items for the first controlled scenario, enter the name without the "<number>" field. To access the items for the 2nd, 3rd, 4th, and 5th controlled scenarios, replace the "<number>" field with "1", "2", "3", or "4". For example, to turn on echoing of the directive lines to the event log for the 5th controlled scenario, enter the following on the directive line with the Scenario module selected to receive it.

```
set Scenario4DirMsg 1
```

To disable the echoing of directive lines to the log for the first controlled scenario, enter

```
set ScenarioDirMsg 0
```

Name	Type	Description
Scenario<number>Currentline	Buffer	Current directive line in scenario file
Scenario<number>DirMsg	Fixed	Flag to list lines read from scenario file (0=no, 1=yes)
Scenario<number>Execution	Fixed	Run flag for scenario execution (0=pause, 1=run)
Scenario<number>Filename	Fixed	Scenario's Filename
Scenario< number >LineNumber	Fixed	Current line number in scenario file
Scenario< number >Status	Fixed	Scenario file's execution status (0=Finished, 1=Running, 99=Paused)

SN-5.0 Displays

To access displays for a module, click in the center of the module in the project window. The following module pop-up menu will appear. There are no configuration screens for the Scenario module. The Run-time option is available only when the project is running. The “Remove” option can be used during project design to remove the module. The “About” option is for the display of the generic module information.

Module Pop-Up Menu Item	Description
Configure	Access Configuration menu for this module
Run-time	Access Run-time menu for this module
Remove	Remove module from the project
About	Display generic module information

SN-5.1 Configure

There are no configuration displays for this module. Refer to section SN-2.1 for information on configuring the scenario execution mode, *ConcurrentScenario*, from the Server/Properties/Property.txt file.

SN-5.2 Run-time


Click on the module pop-up menu “Run-time” option to request the Run-time menu.

Run-time Menu Item	Description
Control	Request Control Scenario Display

SN-5.2.1 Scenario Control Display

Select “Control” from the Run-time menu to show the Scenario Control Display. Up to five scenario files may be controlled and monitored with this display. The fields associated with each file are described in the following table. Click the **Close** button to dismiss the display.


Field	Description
Filename	Enter the full or relative pathname for the scenario file in this field.
File browser 	Click on this button to the right of the filename field to invoke file browsing to select a file.
Start/Stop Button	This button's title changes to Start or Stop as appropriate. To start processing an entered file, click its Start button. To stop an executing file, click its Stop button.
Pause/Resume Button	This button's title changes to Pause or Resume as appropriate. To temporarily stop the processing of a scenario file, click its Pause button. To resume a file after pausing, click its Resume button.
Line No.	This field shows the line position within the file.
Cur. Line	This field shows the text of the most recently executed line.
Status	This field shows “Running”, “Paused”, or “Finished”.



SN-5.2.2 Scenario File Browser

When any of the file browser buttons is selected from the Scenario Control Display, a file selection display similar to the next screen will be displayed. The current search directory will be shown in the File field. Double click on the appropriate folder icons to navigate to the desired directory. Double click on the ".." folder to go up the directory structure. Double click on a named folder to display its contents. Double click to select a scenario file name. The file name should then appear in the File field. Use the **Apply** button to transfer the selected file name to the control display. Use the **Close** button to

dismiss the display without selecting a file. When a file is selected in this manner, its directory then becomes the current search directory for the next file browse action.



Note: The file browser cannot navigate to a disk drive other than the drive where the server software is installed.

SN-5.3 About

Selecting the “About” option from the Scenario module pop-up menu produces a display that lists the module’s number of input and output channels, whether operator directives are allowed, names of authors, and the version number.

SN-6.0 Special Operating Instructions

SN-6.1 Built-in Delays in Scenario Files

Because of the fast processing of scenario files (e.g. 300 directives or more per second), the GUI Event Message window may become jammed by the volume of event messages produced in a very short time. Consequently, other displays may also be “hung up” by this undesirable effect. A proper remedy is under investigation. In the meantime it is suggested that delays be built into the scenario files so that only 20 directives are executed each second.

```
; Sample scenario file
Set MOD_SS_DRNADSTEP 1
SET CEF_NR_ETRQ_1 2
SET AS2_TS_DETECTOR 3
SLEEP 1000
SET AMR_NR_MWASPEED 65
SET AMR_SS_BITPKT1 1
SET AMR_SS_BITPKT4 1
SLEEP 125
```

```
SET EPS_SS_MAINBUSVR 0xFF
sleep 5000
SETBUFFER TLMPACKET0140 20 BYTE 0xA 10 012
```

SN-6.2 Stopping Nested or Triggered Scenarios

Even though the user does not have control over the execution of scenarios started internally, it is possible to stop them without shutting down the simulator. To stop all ongoing scenario files of all types, click on the Project's Run menu and select the "Stop" option. The user should then immediately click on the "Run" option to restart the entire project. Since all of the modules will be stopped briefly, there could be dropouts in data and other consequences. The scenario module does not automatically restart any scenario files when restarted after a project stop.

Serial Input (SI) Module

SI-1.0 Overview

The Serial Input (SI) module provides the capability to receive serial data through a port on an ICS serial card in the host computer and to pass the data received to other modules.

SI-2.0 Input

The SI module does not have any input channels.

SI-3.0 Output

Channel	Description
1	Data received from the serial port is passed on this channel

SI-4.0 Container Items

The SI module's container items are not accessible via operator directives, so they are not listed here.


SI-5.0 Displays

To access displays for this module, click in the center of the SI module in the project window. The following module pop-up menu choices will appear. The "Configure" and "Remove" options are only available during project design. The "Run-time" option is only available when the project is running.


Module Pop-up Menu Item	Description
Configure	Access the Serial Input configuration window
Run-time	Access the module's run-time menu
Remove	Remove the module from the project
About	Display generic module information

SI-5.1 Configuration

Select the "Configure" item from the module pop-up menu to access the configuration window for the Serial Input module.



The default configuration is for the Sim Input Type. When the Input Type field is set to Sim, the Command Information section is enabled for entry and the SubFrame section is disabled.



When "PDP" is selected as the Input Type, the "SubFrame" options will be enabled, "Command Information" will be disabled, and "Frame Size" replaces "FIFO Size" within the Sync section of the display.

Parameter	Description
Mode	Select the Pulse Code Modulation (PCM) decoding method of the input stream from NRZ-L, NRZ-M, or NRZ-S
Data Orientation	Select “LSB” if the data stream is received with the least significant bit first. Select “MSB” if the data stream is received with the most significant bit first.
Data Format	Select “True” if the polarity of the data stream is normal. Select “Inverted” if the polarity of the data stream is inverted. Select “Auto Polarity Check (APC)” if the polarity is unknown.
Channel	Select “Channel A” or “Channel B” for the operation. “Channel A” refers to the first ICS board installed in the system, while “Channel B” refers to the second one.
Sync Pattern	Enter the synchronization pattern in hexadecimal format for the serial I/O card to receive data (maximum 8 digits).
Sync Size	Enter the size of the synchronization pattern in bits (maximum 32 bits)
Frame Size	Enter number of bytes per frame to be received (maximum 4096 bytes).
FIFO Size or Frame Size	Enter the FIFO’s size (maximum 4096) in “SIM” mode. Enter the data frame size (maximum 4096 bytes) in “PDP” mode
Num. FIFO	Enter number of FIFO to receive data (maximum 99)
Input Type	Select “PDP” if the input stream is telemetry. Select “SIM” if the input stream is command.
Tail Sequence	If the command bit stream has a tail sequence, check this box.
Tail Length	Enter the command tail sequence size in bytes (maximum 8 bytes)
Tail Pattern	Enter the command tail sequence pattern in hexadecimal digits (maximum 16 digits).
Max Cmd Size	Enter the maximum command size expected in bytes (maximum 4096 bytes)
Maximum Value	Enter telemetry subframe’s maximum value.
Minimum Value	Enter telemetry subframe’s minimum value.
Size	Enter telemetry subframe size in bits (maximum 16 bits)
Starting Location	Enter the starting location for the telemetry subframe in bits (greater than 32)


Click **Apply** button to configure any changes. Click **Close** button to dismiss the display.

SI-5.2 Run-time

Click the module pop-up menu “Run-time” option to access the Run-time menu with the following choices.

Run-time Menu Item	Description
Display Status	Show the Status window of the Serial Input module
Display Dump	Show the Dump formats available
Resume	Restart the module
Pause	Stop the module

SI-5.2.1 Display Status



This display shows the number of frames and sub-frames that have been received and dropped. It also shows the current configuration settings. Please refer back to the table in section SI-5.1 for descriptions of the settings.


Search Mode and Sub Frame status fields are only applicable when receiving telemetry data.

Click any **Reset** button to change its associated counter to zero.

Click the **Close** button to dismiss the display.

SI-5.2.2 Display Dump

Select the “Display Dump” option to view the available dump options. Currently there is only one format available. When this option is selected the data received from the serial I/O port is displayed.



Button	Description
Addr Mode	Select “Hex” to display the memory address in hexadecimal format Select “Dec” to display the memory address in decimal format
Data Mode	Select “Hex” to display data in hexadecimal format Select “Oct” to display data in octal format
Pause	Pause updating the data contained in the window. The button name changes to Cont .
Cont	Continue updating a previously paused display. The button name changes to Pause .
Close	Close the window

SI-5.2.3 Resume

After an individual module's execution has been paused, select “Resume” from the Run-time menu to restart the module. The color around the module's border will change from red (indicates stopped state) to green (indicates run state).

SI-5.2.4 Pause

Select the “Pause” option from the Run-time menu to temporarily stop the Serial Input module's processing. The color around the module's border will change from green (indicates run state) to red (indicates stopped state). The Serial Input module can be re-configured by selecting the “Configure” option of the module pop-up menu. To return to run mode, select the “Resume” option.

SI-5.3 Remove

Select this option to remove the Serial Input module from the project.

SI-5.4 About

Selecting the “About” option from the module pop-up menu produces a display that lists the number of input channels, number of output channels, whether directives are allowed, names of authors and the module’s version number.

SI-6.0 Special Operating Instructions

There are no special operating instructions for this release.

Serial Output (SO) Module

SO-1.0 Overview

The Serial Output (SO) module provides the capability to transmit serial data through ports on an ICS serial card in the host computer.

SO-2.0 Input

Channel	Description
1	Receive data from upper module through this channel

SO-3.0 Output

Channel	Description
1	Pass transmitted data to next module through this channel

SO-4.0 Container Items

The module's container items are not accessible via operator directives, so they are not listed here.


SO-5.0 Displays

To access the displays for this module, click in the center of the module in the project window. The module pop-up menu will appear with the following choices. The "Configure" and "Remove" options are only available during project design. The "Run-time" option is only available when the project is running.

Module Pop-up Menu Item	Description
Configure	Access the Serial Output configuration window
Run-time	Access to module's Run-time menu
Remove	Remove the module from the project
About	Display generic module information

SO-5.1 Configuration

Select the "Configure" item of the module pop-up menu to access the configuration window of the Serial Output module.



Parameter	Description
Mode	Select the PCM encoding method of the data stream from NRZ-L, NRZ-M, NRZ-S, BIO-L, BIO-M, or BIO-S.
Clock Type	In this version, only the internal clock is used.
Clock Frequency	Enter the frequency in Hz to transmit data out.
Data Orientation	Select “LSB” if the data stream is transmitted with the least significant bit first. Select “MSB” if the data stream is transmitted with the most significant bit first
Channel	Select “Channel A” or “Channel B” for the operation. “Channel A” refers to the first ICS board installed in the system while “Channel B” refers to the second one.
Data Format	Select “True” if the polarity of the data stream is normal. Select “Inverted” if the polarity of the data stream is inverted.
Data Encoding	Click the appropriate boxes to enable “CRC-16”, “Reed-Solomon”, “Randomization”, “Convolution” or “Pseudo-random Noise” encoding.
Frame Length	Enter the frame length in bytes before encoding (maximum 4096 bytes)
Interleave	If “Reed-Solomon” encoding is enabled, enter the length in bytes for interleave.
Virtual Fill	If “Reed-Solomon” encoding is enabled, enter number of bytes for virtual fill.
Frame Size	Enter total number of bytes per frame to be transmitted (maximum 4096 bytes)
Num. FIFO	Enter number of FIFO to contain transmitting data (maximum 99)


Click on **Apply** button to configure any changes. Click on **Close** to dismiss the display.

SO-5.2 Run-time

Click on the module pop-up menu “Run-time” option to request the Run-time menu.

Run-time Menu Item	Description
Display Status	Show the status window of the Serial Output module
Display Dump Menu	Show options for displaying data within a frame
Resume	Restart the module
Pause	Stop the module

SO-5.2.1 Display Status



This display shows the current frame counter and the currently configured settings. Please refer to the table in section SO-5.1 for descriptions of the settings.


Click **Reset** to clear the frame counter to zero.

Click **Close** to close the window.

SO-5.2.2 Display Dump

Select the “Display Dump” option to view the available dump formats. Currently there is only one format available. When this option is selected, the output data buffer is displayed. This display has the following standard dump buttons.

Buttons	Description
Addr Mode	Select “Hex” to display the addresses in hexadecimal format Select “Dec” to display the addresses in decimal format
Data Mode	Select “Hex” option to display data in hexadecimal format Select “Oct” option to display data in octal format
Pause	Freeze the data window contents. Pause button is renamed Cont .
Cont	Resume updating the data window contents. Cont button is renamed Pause .
Close	Close the window



SO-5.2.3 Resume

After an individual module has been stopped, select “Resume” from the Run-time menu to restart the module. The color around the module’s border will change from red (indicates stopped state) to green (indicate run state).

SO-5.2.4 Pause

Select “Pause” from the Run-time menu to temporarily stop the Serial Output module’s processing. The color around the module’s border will change from green (indicates run state) to red (indicates stopped state). The Serial Output module can be re-configured by selecting the “Configure” option of the module pop-up menu. To return to run mode, select “Resume” from the Run-time menu.

SO-5.3 Remove

Select this option to remove the Serial Output module from the project.

SO-5.4 About

Selecting the “About” option from the module pop-up menu produces a display that lists the number of input channels, number of output channels, whether directives are allowed, names of authors and the module’s version number.

SO-6.0 Special Operating Instructions

There are no special operating instructions for this release.

Transmit File (TxFile) Module

TxFile-1.0 Overview

The Transmit File (TxFile) module reads in data from a file according to user-defined parameters and sends the data out unformatted. It operates in either manual mode, where data blocks are loaded and sent out one at a time under user control, or automatic mode, where data blocks are loaded and sent out under user-defined parameters. TxFile can transmit the data in IP transmission mode or in serial transmission mode. TxFile can process a file in normal order or reversed order (the first byte of the file is read and sent out as last byte, the last byte of the file is read and sent out as first byte). If the data file was created by the Log Module and has log headers, it is possible to retransmit the file with the same relative timing between blocks.

TxFile-2.0 Inputs

The TxFile module does not technically have any input channels. It is not possible to create an input link to this module. Its lone output channel is actually bi-directional, providing the down-linked module an optional method for controlling the flow of output data. This method is only used when the TxFile is connected to a module requesting serial transmission of data.

TxFile-3.0 Outputs

Channel	Description
1	Data read from file

TxFile-4.0 Container Items

This module accepts operator directives and is capable of receiving directives from a Scenario module. Use the Set and Get directives to access items with a fixed, integer, float, or string types. Use the SetBuffer and GetBuffer directives on buffer types. Although names in the following tables contain upper and lower case, directive lines are not case sensitive.

Name	Type	Description
TxFileName	String	Pathname of file to send
TxFileStart	Integer	The position of the first block begin to read
TxFileSize	Fixed	Size of file in bytes
TxFilePosition	Integer	Current file pointer position
TxFileTransmitCount	Integer	Number of blocks transmitted
TxFileTransmitBuffer	Buffer	Most recent buffer loaded from file
TxFileBlockSize	Integer	Size of block to load and then transmit
TxFileReversed	Integer	Reversed order flag
Tx FileMode	Integer	File Read Modes: (1) Offset (2) Log file (playback a logged file with header) (3) Sync (4) Length

		Note: (3) & (4) not implemented yet
Tx FileMode Offset	Integer	Offset from the start position of previous block
Tx File Log Timing	Integer	Use log file timing instead of the interval
Tx File Auto	Integer	Automatic or manual mode flag
Tx File Load	Integer	Flag to load a block
Tx File File Loop Flag	Integer	Flag for number of times a whole file to be read and sent out
Tx File Loop Count	Integer	Number of times a whole file to be read and sent out. Note: a whole file would be read and sent out indefinite times if the counter is set to be equal or less than 0.
Tx File Block Flag	Integer	Flag for number of blocks to be read and sent out
Tx File Read Count	Integer	Number of blocks to be read
Tx File Send Count	Integer	Number of times each block to be sent out
Tx File Interval	Float	Interval between two blocks being sent in milliseconds
Tx File Send	Integer	Flag to start transmission
Tx File Continue Send	Integer	Flag to continuously transmit
Tx File Stop	Integer	Flag to stop transmission
Tx File Transmit Mode	Integer	Output transmission mode (0=IP (default), 1=serial, 2=force IP mode)
Tx File Serial Status	Integer	Serial transmission status (0=stopped automatically, 1=stopped by operator, 2=running, 3=waiting for send key)

TxFile-5.0 Displays

To access the displays for this module, first click on the center of the module in the project window. The following items will appear in a pop-up menu.

Module Pop-Up Menu Item	Description
Configure	Access the configuration menu for the module
Run-time	Access the Run-time menu for the module
Remove	Remove module from the project
About	Display generic module information

TxFile-5.1 Configuration Displays


There are no configuration displays for this module. However, if during run-time TxFile receives a request for more data signal from the down-linked module, the transmission mode will be automatically reconfigured to serial and an event message will be generated to inform the operator.

TxFile-5.2 Run-time Displays

Run-time Menu Item	Description
Display Status	Display TxFile module status
Display Transmit Buffer	Display current block for transmission
Send From File	Control TxFile module processing

TxFile-5.2.1 Status Display


The status display shows the current filename, the size of the file, current file pointer position, and the total number of blocks transmitted.



Status Display Field	Description
File Name	Pathname of the file being transmitted
File Size	Size (in bytes) of the file being transmitted
Current Position	Current byte position in file
Total Transmit	Total number of blocks transmitted
Reset	Click to clear the Total Transmit count

TxFile-5.2.2 Transmit Buffer Display


The transmit buffer display shows the contents of the currently loaded block.



The address field of the dump display may be toggled between hexadecimal and decimal display formats. The data portion may be toggled between hexadecimal and octal formats. The screen contents may be "frozen" using the **Pause** button. Paused data may be "unfrozen" with the **Cont** button.

TxFile-5.2.3 Send From File

The send from file display is the main operations display. This display allows the user to specify data files, specify read mode parameters, specify output mode parameters and control the data transmission. The following description mainly applies to the default IP transmission mode. For a description of this display's operation from serial transmission mode, see section TxFile-5.2.3.7 Example 5 Serial Transmission Mode.



This is the initial Send from File Display before any parameters have been set. The default interval (for automatic transmission) is 2000 milliseconds (2 seconds) between blocks. The default read mode is Offset. The default output mode is Manual.

File Information	Description
Filename	Pathname of the file to transmit can be relative or absolute (leading or trailing white space is allowed, but not embedded spaces).
File browser [...]	Click on this button to the right of the filename field to invoke file browsing to select a file.
Start pos	Starting position (in bytes) within the file of the first block to send.
Blocksize	Size of block to read (in bytes).
Reverse Order	If set, the file is transmitted in reversed order (the first bit of file is transmitted as the last bit, last bit of file is transmitted as first bit).

File Read Mode	Description
Offset button	Click to select Offset read mode
Offset field	Increment (in bytes) between the start of consecutive blocks. Should normally be the same as the block size. If zero, the same block would be read and sent out repeatedly.
Sync	(Not yet implemented) Sync mode -- Look for a sync pattern in the file as given by the bit size and the bit pattern and send out the number of bytes given by block size starting with and including the sync pattern.
Length	(Not yet implemented) Length mode -- Look for a length value in the file as given by the bit offset after the end of the previous block. Pick up the number of bits given, add the adjustment, and use that as the length of the block to send.
Log file	Specify a Log Module file with log headers
Use log file timing	Use relative timing from the log headers instead of the Interval to transmit data blocks
Output Mode	Description
Manual	(Manual mode) Data blocks are loaded and sent out one at a time under user control
Auto-Complete File	(Automatic mode) Transmit a whole file the specified number of Cycles .
Cycles	To transmit the file a fixed number of times, set Cycles to a nonzero value (default value is 1). To transmit the file an indefinite number of times, set Cycles to zero. Note: If the "Offset field" is set to zero, the end of file is never reached and the same block will be transmitted repeatedly until stopped.
Auto-Blocks	(Automatic mode) Transmit a portion of a file, indicated by setting Blocks Read and Blocks Sent (both are 1 by default).
Blocks Read	Number of blocks to read
Blocks Sent	Number of times each read block is sent out. Note: If this field is less than or equal to 0, the blocks read are sent out repeatedly until stopped.
Interval	Interval between block transmission (in milliseconds).
Operation	Description
Load	(Manual mode only) Loads the next block from the file.
Send	Manual mode: Sends the currently loaded block one time. Automatic modes: Starts the specified automatic transmission.
Continuously	(Auto-Blocks mode only) Pressing the Send button sends out the current block. Pressing the Continuously button will make the next block the current block and send it out.
Stop	(Automatic modes only) Stop sending blocks.
Apply	Configuration values are used only after this button is pressed.
Close	Close this window.

TxFile-5.2.3.1 File Browsing

When the file browser button is selected from the TxFile Transmit Display, a file selection display similar to the next screen will be displayed. The current search directory will be shown in the File field. Double click on the appropriate folder icons to navigate to the desired directory. Double click on the ".." folder to go up the directory structure. Double click on a named folder to display its contents. Double click to select a scenario file name. The file name should then appear in the File field. Use the **Apply** button to transfer the selected file name to the control display. Use the **Close** button to dismiss the display without selecting a file. When a file is selected in this manner, its directory then becomes the current search directory for the next file browse action.



Note: The file browser cannot navigate to a disk drive other than the drive where the server software is installed.

TxFile-5.2.3.2 File Types

Any type of data file may be used with varying degrees of success. Depending on the type of file, different modes of operation should be used. Currently this module only recognizes two basic file types.

Raw data:	Any file that contains data bytes only. It contains no additional bytes preceding or following the data bytes. An example of a raw data file is any log file created by the SIMSS Log Module without the log header option. Raw data files may be received from many other sources.
Log file:	Any file created by the SIMSS Log Module with the log header option enabled. The log header bytes contain data length and log time information.

A file may have fixed or variable length data.

Fixed data:	Every data entry in the file is the same size. When the Log Module creates fixed sized files, some entries may be truncated and others may
-------------	--

	be padded with zero bytes.
Variable data:	Data entries in the file may vary in size. This is usually the most flexible and efficient way to log data.

The following table summarizes read and transmission modes for the different file types and provides a map to applicable examples in the following sections.

File Type	Data Size	Read Modes	Transmit Modes	Examples
Raw data	Fixed	Offset	Manual mode	Example 1
Raw data	Fixed	Offset	Auto-Complete File	Example 2
Raw data	Fixed	Offset	Auto-Blocks	Example 3
Raw data	Varying	None apply	None apply	None apply, see note
Log file	Fixed or Varying	Log file	Manual mode	Example 1
Log file	Fixed or Varying	Log file	Auto-Complete File	Example 2
Log file	Fixed or Varying	Log file	Use Log file timing	Example 4


Note Since the Sync and Length read modes are not yet implemented, TxFile can not properly process raw files with varying size data. Every data byte can be read and transmitted using modes valid for fixed raw files, but the timing and grouping of the data may not be valid for the receiving system. These files should be converted to fixed data size files. When varying length data is recorded with the Log module for later TxFile playback, the log header option must be enabled.

The next five sections provide examples for using the different output modes. The steps given in each example are the minimum steps required. Review the parameter description table at the beginning of section 5.2.3 for more information.

TxFile-5.2.3.3 Example 1 Manual Mode Transmission

Step	Manual Mode Transmission Description
1	Enter the file name in the Filename field.
2	Select Manual Output Mode if it is not already on. If the Output Modes are not available for selection, click to select the Offset File Read Mode first.
3	For raw data files, click to set Offset File Read Mode and enter the fixed data size in bytes in the Blocksize and Offset fields. For log files, click to set the Log file option.
4	Click Apply button and note any error messages in the event message log. If necessary correct the file name and repeat this step until there are no errors.
5	Click Load button to read in the next entry of the file.
6	Click Send button to transmit the loaded entry one time.
	Repeat steps 5 and 6 as often as needed.


The following screen shows TxFile configured for manual output mode using a raw data file with entries of 256 bytes. Steps 1 through 4 (Apply) have been done. Steps 5 and 6 must be executed to transmit data.



TxFile-5.2.3.4 Example 2 Auto-Complete File Transmission


Step	Auto-Complete File Transmission Description
1	Enter the file name in the Filename field.
2	Select Auto-Complete File in Output Mode region. If the Output Modes are not available for selection, click to select the Offset File Read Mode first.
3	For raw data files, select Offset File Read Mode and enter the fixed size in bytes in the Blocksize and Offset fields. For log files, click to set the Log file option.
4	Enter the desired timing between blocks in the Interval field. (1000 = 1 second)
5	For raw data files only, the Cycles field may be modified to specify the number of times to transmit the file. Set Cycles to zero for an indefinite number of times.
6	Click Apply button and note any error messages in the event message log. If necessary correct the file name and repeat this step until there are no errors.
7	Click Send button to start the automatic transmission. Transmission will stop when the file has been transmitted the specified number of cycles. Transmission does not automatically stop for raw files when the Offset field or the Cycles field is set to zero. Log files are only transmitted one time.
8	Click Stop button to stop the automatic transmission at any time.

The following screen shows TxFile configured for Auto-Complete File output mode using a raw data file with entries of 256 bytes. The entire file will be transmitted 3 times with 5 seconds between blocks. Steps 1 through 6 (Apply) have been done. A single click on the Send button will start the transmission.



TxFile-5.2.3.5 Example 3 Auto-Blocks Transmission (Raw Fixed Data Files Only)

Step	Auto-Blocks Transmission (Raw Fixed Data Files Only)
1	Enter the file name in the Filename field.
2	Select Auto-Blocks in the Output Mode region. If the Output Modes are not available for selection, click to select the Offset File Read Mode first.
3	Set Offset File Read Mode if not already set and enter the fixed data size in bytes in the Blocksize and Offset fields.
4	Enter the desired timing between blocks in the Interval field. (1000 = one second)
5	Enter the number of blocks to read in the Blocks Read field.
6	Enter the number of times to transmit each block in the Blocks Sent field. If this field is set to zero, the same block will be sent until the Continuously button is used to force loading of the next block.
7	Click Apply and note any error messages in the event message log. If necessary correct the file name and repeat this step until there are no errors.
8	Click Send to start the automatic transmission. If Blocks Read specifies a finite value, the transmission will stop after the specified blocks have been sent the specified number of times.
9	If the Blocks Read field was set to zero, click on Continuously button when desired to cause loading and sending of the next block.
10	Click Stop to stop the automatic transmission at any time.




The above screen shows TxFile configured for Auto-Blocks output mode using a raw data file with entries of 256 bytes. The first 2 blocks of the file will be transmitted 3 times with 1500 milliseconds between blocks. Steps 1 through 7 (Apply) have been done. A single click on the Send button will start the transmission.

TxFile-5.2.3.6 Example 4 Use of Log File Timing (Log Files Only)

Step	Use of Log File Timing (Log Files Only)
1	Enter the log file name in the Filename field.
2	Select Auto-Complete File in Output Mode region. If the Output Modes are not available for selection, click to select the Offset File Read Mode first.
3	Click to select the Log file option.
4	Click to select the Use log file timing option. Relative timing between blocks will be calculated from the time tags in the log headers.
5	Click Apply and note any error messages in the event message log. If necessary correct the file name and repeat this step until there are no errors.
6	Click Send to start the automatic transmission of the file using log file timing. Transmission will stop when the file has been sent one time.
7	Click Stop to halt the automatic transmission before completion.

The following screen shows TxFile configured for Auto-Complete File mode using log file timing. Steps 1 through 5 (Apply) have been done. A single click on the Send button will start the transmission.



TxFile-5.2.3.7 Example 5 Serial Transmission Mode

When TxFile is linked to a module requesting serial output, the transmission mode is automatically changed to serial transmission mode. When an Automatic output mode is selected, the module requesting serial data will control the timing of the transmissions. The operator may specify the file to read, read parameters and the number of times to transmit the file. Specification of log file timing or an interval will be ignored. Event messages will inform the operator when the mode is changed to serial, when transmission starts, when transmission stops, and each time the end-of-file is reached.

Note: Use of Manual mode with serial transmit mode is the same as with IP transmit mode. Refer to the previous Manual example for instructions.

Note: Should the operator want to override the serial timing and use the operator-specified interval or log file timing options, use the following directive to force the transmit mode to stay in IP mode. Then follow any of the other examples.

Set TxFileTransmitMode 2

Step	Serial Transmission Mode
1	Enter the file name in the Filename field.
2	Select Auto-Complete File in the Output Mode region. If the Output Modes are not available for selection, click to select the Offset File Read Mode first.
3	For raw data files, select Offset File Read Mode and enter the fixed size in bytes in the Blocksize and Offset fields. For log files, click to set the Log file option.
4	Set the Cycles field to the number of times to transmit the file. Set Cycles to zero

	to specify an indefinite number of times.
5	Click Apply and note any error messages in the event message log. If necessary correct the file name and repeat this step until there are no errors.
6	Click Send to start the serial transmission. Transmission will automatically stop when the file has been sent the specified number of times.
7	Click Stop to halt the serial transmission before completion.
8	Optionally click Send to resume or repeat the serial transmission. If the transmission was previously stopped, it will be resumed at the halted position in the file. If the end of transmission was reached, the original request will be repeated. If the Send button is not available, click on the Stop button first.

TxFile-5.3 About Display

Clicking the “About” option of the module pop-up menu requests a display that lists information about the module such as the numbers of input and output channels and whether the module accepts operator directives.

TxFile-6.0 Special Operating Instructions

- It is important to specify the appropriate read mode for the data file type (see TxFile-5.2.3.2 File Types). If a raw data file is read using the Log file mode, data bytes will be interpreted as log header fields and may cause the TxFile module to crash. If a log file is read using the Offset mode, the log header fields will be incorrectly transmitted as part of the data.
- When using the Auto-Complete File and Auto-Blocks Output modes, it is critical to set the Interval field properly. This field is in milliseconds. If a very short interval is used, an entire file may be transmitted multiple times in a brief period. In some configurations, the automatic transmission does not stop without operator intervention. This may overwhelm the resources of the sending system or that of the receiving system.
- There are several limitations when using Log files. When some of the following options are selected, they currently do not work and there are no error event messages.
 - 1) The Auto-Blocks output mode does not work with log files. (If Auto-Blocks is selected with use log file timing, TxFile processes the request as Auto-Complete File with log file timing.)
 - 2) When using the Auto-Complete File output mode with log files, the file is only transmitted once. It does not matter how the Cycles field is set.
 - 3) A starting offset (Start pos) cannot be used with log files. If specified, it will be ignored. The log file will be read from the beginning.
 - 4) Reverse order should not be used with log files.
- The Auto-Blocks output mode does not work in Serial Transmit mode.

Generic VC Processor Module

VC Processor-1.0 Overview

The Generic CCSDS Virtual Channel (VC) Processor is used to monitor and verify virtual channels on a CCSDS data stream.

VC Processor-2.0 Inputs

The VC Processor module has a single input channel.

Channel	Description
1	Accepts external data stream of CCSDS data. Data must be synchronous and contain exactly one VC packet per data burst.

VC Processor-3.0 Outputs

The VC Processor module has three separate output channels. The output for each channel is user configurable (see below for configuration instructions).

Channel	Description
1, 2, 3	Sends user-defined channels to other modules.

VC Processor-4.0 Container Items

Container Name	Description
VCCRCCheck	Enable/disable CRC checking. (0 = disable, 1 = enable)
VCRSCheck	Enable/disable RS checking. (0 = disable, 1 = enable)
Interleave	The value for interleave. This is only used if RS checking is enabled.
Virtualfill	The value for virtual fill. This is only used if RS checking is enabled.
Displayarray	The status of each channel. This updates the colored boxes in the runtime display (0 = yellow, 1 = green, 2 = red).
Container Name for each VC. XX represents a decimal number (00 – 63)	Description – each container item is specific to a single VC
NumVCXX	The number of VCDU/Transfer Frames.
VCSeqErrsXX	The number of sequence errors.
VCCRCXX	The number of CRC errors.
VCRSErr	The number of RS errors.
VCUncorrRSErrXX	The number of uncorrectable RS errors. Note: this is not yet implemented.
VCvallOffset	The telemetry value starting at the offset byte.

OffsetLocation	The offset byte where telemetry extraction will begin.
----------------	--

VC Processor-5.0 Displays


To access displays for a module, click in the center of the module in the project window. The following pop-up menu choices will appear. The “Remove” option can be used during project design to remove the module. The “Configure” option should be used prior to running the project and is unavailable at run-time. The Run-time option is available only when the project is running.

Module Pop-Up Menu Item	Description
Configure	Access the configuration display
Run-time	Access the Run-time menu for the module
Remove	Remove the module from the project
About	Display generic module information

VC Processor -5.1 Configure

There are three different configuration windows: Main Configuration, Set Channel and Set Offset. This module can also be re-configured during runtime.


VC Processor-5.1.1 Main Configuration Window



Field Name	Description
CRC	Enable/disable CRC check.
RS	Enable/disable RS encoding check.
Interleave	Only accessible when doing RS check. Input is a decimal integer.
Virtual Fill	Only accessible when doing RS check. Input is a decimal integer.
Set Channel	Set virtual channels to transmit on each of the three output channels. See 5.1.2 for more details.
Set Offset	Set the start byte location for display value (one per virtual channel). See 5.1.3 for more details.

This is the main configuration window. CRC and RS checking is enabled/disabled from this window. The two other configuration windows are accessible from this window.

VC Processor-5.1.2 Set Channel



This window is the output channel configuration window. Any number of virtual channels can be transmitted over any of the three module output channels. The checked VCs will be transmitted on the specified channel. In the above picture, module output channel 1 will transmit VCs 18, 29, and 42.

VC Processor-5.1.3 Display Offset

VC 0	0	VC 16	0	VC 32	0	VC 48	0
VC 1	3	VC 17	0	VC 33	0	VC 49	0
VC 2	4	VC 18	0	VC 34	0	VC 50	0
VC 3	3	VC 19	0	VC 35	0	VC 51	0
VC 4	3	VC 20	0	VC 36	0	VC 52	0
VC 5	0	VC 21	0	VC 37	0	VC 53	0
VC 6	0	VC 22	0	VC 38	0	VC 54	0
VC 7	0	VC 23	0	VC 39	0	VC 55	0
VC 8	0	VC 24	0	VC 40	0	VC 56	0
VC 9	0	VC 25	0	VC 41	0	VC 57	0
VC 10	0	VC 26	0	VC 42	0	VC 58	0
VC 11	0	VC 27	0	VC 43	0	VC 59	0
VC 12	0	VC 28	0	VC 44	0	VC 60	0
VC 13	0	VC 29	0	VC 45	0	VC 61	0
VC 14	0	VC 30	0	VC 46	0	VC 62	0
VC 15	0	VC 31	0	VC 47	0	VC 63	0

Buttons at the bottom: Apply, Close.

Each VC will display a 32-bit telemetry value in the runtime Status window (5.2.1). The byte offset (first byte to display) is configured in this window. The first byte in a VC is

byte zero. For example, an offset value of 3 will display bytes 3, 4, 5, and 6 in the Status window when the module is running.


VC Processor-5.2 Run

During runtime, the VC Processor module will perform an analysis of the CCSDS data stream going through it. When the module encounters a new VC in the stream, it will inform the user through status windows and report on the status of each active VC.

The Run-time menu for the VC Processor contains the following five items.

Run-time Menu Item	Description
Show Status	Display the status of each active VC.
Display VC	A “quick” display of all VCs.
ReConfigure	Allows user to reset configuration variables.
Resume	Resumes module.
Pause	Pauses module.

VC Processor-5.2.1 Show Status



This window shows the status of each active VC.

Status Column	Description
VC#	The VC ID (0 – 63).
# of VCs	The number of VCDU/Transfer Frames received for this virtual channel.

SeqErrs	The number of sequence errors encountered for this virtual channel.
CRC	The number of CRC errors encountered for this virtual channel. This will be zero if CRC checking is not enabled.
RS Error	The number of RS errors encountered for this virtual channel. This will be zero if RS checking is not enabled
Uncorr/RS Error	This functionality is not implemented yet.
Value Offset	The 32 bit value taken from telemetry. The location to start extracting data from is found in the configuration window

VC Processor-5.2.2 Display VC



This is a “quick” display of the status of all VCs. The following color code applies:

- | | |
|--------|--------------------------|
| Yellow | Inactive VC |
| Green | Active VC with no errors |
| Red | Active VC with errors |

All VCs start out as inactive. When a VC is encountered in the data stream, the corresponding box turns green or red, depending on quality of data. If a box turns red, the user can click on it, turning it yellow (inactive). A VC box will not change from red to any other color unless the user clicks on it.

VC Processor-5.2.3 ReConfigure

This option allows the user to re-configure the VC Processor module during run-time. Neither the module nor the project needs to be stopped in order to reconfigure. Refer to the configuration section (5.1) for details.

ACRONYMS

APID	Application Identifier
BCH	Bose-Chaudhuri-Hocquenghem
CADU	Channel Access Data Unit
CCSDS	Consultative Committee on Space Data Systems
CLCW	Command Link Control Word
CLTU	Command Link Transmission Unit
COP	Command Operations Procedure
COTS	Commercial, off-the-shelf
CSC	Computer Sciences Corporation
CUC	CCSDS Unsegmented Time Code
EDOS	EOS Data and Operations System
EDU	EDOS Data Unit
EGS	EOS Ground System
EMOS	EOS Mission Operations System
EOSGS	SIMSS module for the EOS Ground Station
EOS	Earth Observing System
EOSDIS	Earth Observing System Data and Information Systems
EPGS	EOS Polar Ground Stations
ESH	EDOS Service Header
ETS	EOSDIS Test System
FARM	Frame Acceptance and Reporting Mechanism
FTP	File Transfer Protocol
GMH	Ground Message Header
GMT	Greenwich Mean Time
GUI	Graphical User Interface
GS	SIMSS Ground Station Module
ICD	Interface Control Document
IP	Internet Protocol
MPS	Multimode Portable Simulator (legacy simulator for AM-1)
MPS/Aura	Common name for the SIMSS/Aura Simulator
NT	New Technology
PC	Personal Computer
PDB	Project Database
SC	SIMSS Spacecraft Module
SCAura	SIMSS Spacecraft Module with Aura extensions
SIMSS	Scalable Integrated Multimission Simulation Suite
SIMSS/Aura	SIMSS-based Aura Simulator (also known as MPS/Aura)
TCP	Transmission Control Protocol
TIE	Transponder Interface Electronics
UDP	User Datagram Protocol
VCDU	Virtual Channel Data Unit
VCID	Virtual Channel Identification